

Roßmann Electronic GMBH GERMANY		stocklist:	
www.rossmannweb.de	FON: 0049 8807-94994-0	dated	
info@rossmannweb.de	FAX: 0049 8807-94994-29	04.10.2019	
Item:	Description:	MFQ.:	stock - items:
1HS41	High temperature switch	Honeywell	1
922AA1Y-B4P-L	proximity switch	Honeywell	1
TD4A	Temperatursensor	Honeywell	4
TD5A	Temperatursensor	Honeywell	100
TD5A-03	Temperatursensor	Honeywell	8
921FS1	proximity switch	Honeywell	1
931FS5G	proximity switch	Honeywell	1
962FSS3,5-C	sensor	Honeywell	2
TD4AS	Temperatursensor	Honeywell	3
922FS0.8-A4P-G	proximity switch	Honeywell	23
AD0612US-A71GL	DC-FAN	ADDA	1700
BHX1-2325-SM	Batteryholder / Batterycontact	MPD	400
UG-568/U	RF Connector	Amphenol	150
1012C	Batteryholder / Batterycontact	Keystone	12
1018	Batteryholder / Batterycontact	Keystone	778
1027	Batteryholder / Batterycontact	Keystone	93
1029 C	Cover for 1029	Keystone	1040
1029LC	Cover for 1029	Keystone	4950
1044	Batteryholder / Batterycontact	Keystone	100
1053	Batteryholder / Batterycontact	Keystone	20
1056TR	Batteryholder / Batterycontact	Keystone	3
1059	Batteryholder / Batterycontact	Keystone	1160
1066	Batteryholder / Batterycontact	Keystone	4384
1081	Batteryholder / Batterycontact	Keystone	18
1089	Batteryholder / Batterycontact	Keystone	2
1090	Batteryholder / Batterycontact	Keystone	2
1096P	Batteryholder / Batterycontact	Keystone	115
1097	Batteryholder / Batterycontact	Keystone	50
1097P	Batteryholder / Batterycontact	Keystone	25
1098	Batteryholder / Batterycontact	Keystone	80
1098P	Batteryholder / Batterycontact	Keystone	20
1102	Batteryholder / Batterycontact	Keystone	50
1114	Batteryholder / Batterycontact	Keystone	2
120	Batteryholder / Batterycontact	Keystone	80
122TR	Batteryholder / Batterycontact	Keystone	2000
138	Batteryholder / Batterycontact	Keystone	101
149	Batteryholder / Batterycontact	Keystone	60
151	Batteryholder / Batterycontact	Keystone	76
230-1	Batteryholder / Batterycontact	Keystone	50
2413	Captive Screw	Keystone	20
2460RB	Batteryholder / Batterycontact	Keystone	500
2468	Batteryholder / Batterycontact	Keystone	153
2482	Batteryholder / Batterycontact	Keystone	1
2490	Batteryholder / Batterycontact	Keystone	2
269	Batteryholder / Batterycontact	Keystone	16
288	Batteryholder / Batterycontact	Keystone	1095
2915	Batteryholder / Batterycontact	Keystone	3
2990	Batteryholder / Batterycontact	Keystone	920
2991	Batteryholder / Batterycontact	Keystone	6810
2996	Batteryholder / Batterycontact	Keystone	1968
2998	Batteryholder / Batterycontact	Keystone	557
3001	Batteryholder / Batterycontact	Keystone	72
3005	Batteryholder / Batterycontact	Keystone	1400
3006TR	Batteryholder / Batterycontact	Keystone	1200
3008	Batteryholder / Batterycontact	Keystone	803
3009	Batteryholder / Batterycontact	Keystone	188
3020	Batteryholder / Batterycontact	Keystone	208
3026	Batteryholder / Batterycontact	Keystone	102

3027	Batteryholder / Batterycontact	Keystone	1032
3096	Batteryholder / Batterycontact	Keystone	-2
400-2802-01-00-20	Batteryholder / Batterycontact	Cambion	250
4814	Nylon Stand	Keystone	6000
482	Handle	Keystone	59
5004	Test Point	Keystone	2
5202	Batteryholder / Batterycontact	Keystone	14245
5203	Batteryholder / Batterycontact	Keystone	5030
5209	Batteryholder / Batterycontact	Keystone	10
5213	Batteryholder / Batterycontact	Keystone	217
5214	Batteryholder / Batterycontact	Keystone	1740
5218	Batteryholder / Batterycontact	Keystone	5
5221	Batteryholder / Batterycontact	Keystone	665
5224	Batteryholder / Batterycontact	Keystone	8264
56TR	Batteryholder / Batterycontact	Keystone	2500
591	Batteryholder / Batterycontact	Keystone	7882
635	Batteryholder / Batterycontact	Keystone	3
7170	Handle	Keystone	42
b	Batteryholder / Batterycontact	Keystone	50
ABG-43	Battery Clip	MPD	3
BC1/3N-C-SM	Batteryholder / Batterycontact	MPD	800
BC3AAPC	Batteryholder / Batterycontact	MPD	99
BC501SM	Batteryholder / Batterycontact	MPD	3
BH212DW	Batteryholder / Batterycontact	MPD	60
BH28DL	Batteryholder / Batterycontact	MPD	2
BH2DW	Batteryholder / Batterycontact	MPD	60
BH3AAW	Batteryholder / Batterycontact	MPD	200
BHD-2	Batteryholder / Batterycontact	MPD	206
MBHCW	Batteryholder / Batterycontact	MPD	147
BCC	Batteryholder / Batterycontact	MPD	700
BK885	Batteryholder / Batterycontact	MPD	2632
ABG-44	Battery Clip	MPD	50
BC2032-E2	Batteryholder / Batterycontact	MPD	100
BC2AAAW	Batteryholder / Batterycontact	MPD	700
BC34AASF	Batteryholder / Batterycontact	MPD	5
BC4AAAW	Batteryholder / Batterycontact	MPD	120
BC501SMTR	Batteryholder / Batterycontact	MPD	500
BCCA	Batteryholder / Batterycontact	MPD	1708
BCAAAPC	Batteryholder / Batterycontact	MPD	300
BH13CW	Batteryholder / Batterycontact	MPD	150
BH16AAW	Batteryholder / Batterycontact	MPD	10
BH210CL	Batteryholder / Batterycontact	MPD	50
BH2AAAPC	Batteryholder / Batterycontact	MPD	5
BH2CL	Batteryholder / Batterycontact	MPD	100
BH2CW	Batteryholder / Batterycontact	MPD	100
BH2NW	Batteryholder / Batterycontact	MPD	150
BH4CW	Batteryholder / Batterycontact	MPD	80
BHAA-POL	Batteryholder / Batterycontact	MPD	200
BHDW	Batteryholder / Batterycontact	MPD	100
BHSD-2032-L	Batteryholder / Batterycontact	MPD	20
BHX1-1632-SM	Batteryholder / Batterycontact	MPD	937
BK-204	Batteryholder / Batterycontact	MPD	20
BK-209	Batteryholder / Batterycontact	MPD	790
BK-228	Batteryholder / Batterycontact	MPD	720
BK-5091	Batteryholder / Batterycontact	MPD	500
BK-868	Batteryholder / Batterycontact	MPD	48
BK-870	Batteryholder / Batterycontact	MPD	5
BK-883	Batteryholder / Batterycontact	MPD	660
BK-885	Batteryholder / Batterycontact	MPD	5
BK-912	Batteryholder / Batterycontact	MPD	258
BK-1279	Batteryholder / Batterycontact	MPD	8
BLP2016SM-GTR	Batteryholder / Batterycontact	MPD	20
BSR	Batteryholder / Batterycontact	MPD	2420

BU2032SM	Batteryholder / Batterycontact	MPD	5
BU2450SM-JJ-GTR	Batteryholder / Batterycontact	MPD	4250
BVSD-2032-COVER	Batteryholder / Batterycontact	MPD	20
BVSD-2032-PC	Batteryholder / Batterycontact	MPD	40
CB-AA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AA-PC-POS	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-POS	Batteryholder / Batterycontact	MPD	120
392 SONY	Coin Cell	Sony	8
395 SONY	Coin Cell	Sony	30
CR 2032 PANASONIC	Coin Cell	Panasonic	15
CR 2032 VARTA	Coin Cell	Varta	300
CR 2032BLISTER	Coin Cell	Varta	45
CR1620 SONY	Coin Cell	Sony	500
CR2450HT RENATA	Coin Cell	Renata	105
CR3032	Coin Cell	Panasonic	220
ER14505 / EVE	Coin Cell	EVE	10
AAA ENELOOP NIMH BUL	Battery	Eneloop	1000
LR03/AAA/PROCELL/10P	Battery	Duracell	20
LR20 PROCELL	Battery	Duracell	30
LR6/PROCELL	Battery	Duracell	155
CDRH6D23HP	inductive component	SUMIDA	2000
1RA1	switch	Honeywell	2
1PB5-T	Push Buttons	Honeywell	1
111SM2-T	Subminiature Basics	Honeywell	4
311SM6-T	Subminiature Basics	Honeywell	1
311SM1-T	Subminiature Basics	Honeywell	10
11SM3-S	Subminiature Basics	Honeywell	1
11SM1-N102	Subminiature Basics	Honeywell	6
111SM1-T	Subminiature Basics	Honeywell	3
311SM701-T	Subminiature Basics	Honeywell	2
311SM7604-H4	Subminiature Basics	Honeywell	3
311SM5-T	Subminiature Basics	Honeywell	5
311SM1-H2	Subminiature Basics	Honeywell	1
311SM702-T	Subminiature Basics	Honeywell	5
11SM23-H58	Subminiature Basics	Honeywell	3
311SM201	Subminiature Basics	Honeywell	3
311SM4-T	Subminiature Basics	Honeywell	6
311SM1	Subminiature Basics	Honeywell	2
311SM56	Subminiature Basics	Honeywell	1
311SM2-T	Subminiature Basics	Honeywell	1
311SX4-T	Subminiature Basics	Honeywell	1
11SM1	Subminiature Basics	Honeywell	10
1SM22	Subminiature Basics	Honeywell	5
411SM1	Subminiature Basics	Honeywell	2
11SM701-T	Subminiature Basics	Honeywell	5
1SM2-T	Subminiature Basics	Honeywell	5
11SM3-T	Subminiature Basics	Honeywell	3
41SM1-T	Subminiature Basics	Honeywell	3
11SM1-T24	Subminiature Basics	Honeywell	5
11SM244-T	Subminiature Basics	Honeywell	1
313SX2-T	Subminiature Basics	Honeywell	2
103MG5	Subminiature Basics	Honeywell	2
11SM23-T	Subminiature Basics	Honeywell	1338
11SM243-T	Subminiature Basics	Honeywell	45
11SM701-T	Subminiature Basics	Honeywell	75
11SX21-T	Subminiature Basics	Honeywell	2
12SM4-T	Subminiature Basics	Honeywell	359
12SX3-T	Subminiature Basics	Honeywell	175
1LS19-4PG	Industrial Limit Switches	Honeywell	14
1LS2-4PG	Industrial Limit Switches	Honeywell	6
1LS244-4PG	Industrial Limit Switches	Honeywell	9
1LS3-4PG	Industrial Limit Switches	Honeywell	7

1LS47-4PG	Industrial Limit Switches	Honeywell	2
1PA4	Industrial Limit Switches	Honeywell	10
1TB1-1	Large Basics	Honeywell	1
1TB1-3	Large Basics	Honeywell	6
1XE301	Aero Sealed Switch Legacy	Honeywell	1
201LS2-4	Industrial Limit Switches	Honeywell	1
20PCWHRC	20PC option part	Honeywell	16
2455R-00820688	Commercial Thermal	Honeywell	1
24PCFFA6G	PCB pressure sensor	Honeywell	3
26PCCFA1G	PCB pressure sensor	Honeywell	1
26PCCFA6G	PCB pressure sensor	Honeywell	1
2MN1M/1PA22-4	Industrial Limit Switches	Honeywell	20
2MN8M/1PA39-4	Industrial Limit Switches	Honeywell	15
2SX1-T	Subminiature Basics	Honeywell	7
2TL1-1	Toggles & Rockers	Honeywell	1
2TL49-5K	Toggles & Rockers	Honeywell	1
2TL5-7	Toggles & Rockers	Honeywell	2
2TM-15T-7	Switch	Honeywell	57
311SM2-T	Subminiature Basics	Honeywell	318
311SM3-T	Subminiature Basics	Honeywell	4
311SM6-T	Subminiature Basics	Honeywell	3
311SM7-T	Subminiature Basics	Honeywell	18
311SX2-T	Subminiature Basics	Honeywell	1
313SX3-T	Subminiature Basics	Honeywell	1
3PA2	Industrial Limit Switches	Honeywell	3
411SM1	Subminiature Basics	Honeywell	3
4TL1-2	Toggles & Rockers	Honeywell	5
4TL1-8	Toggles & Rockers	Honeywell	1
511TS1-1	Toggles & Rockers	Honeywell	33
511TS1-2	Toggles & Rockers	Honeywell	1
5LS1-4PG	Industrial Limit Switches	Honeywell	3
5SE1	Subminiature Basics	Honeywell	7
5XE1-6	Aero Sealed Switch Legacy	Honeywell	1
5SE1-6N26	Aero Sealed Switch Legacy	Honeywell	12
6655-90980004	Thermistors	Honeywell	38
6655-91000001	Thermistors	Honeywell	48
6HM1-3	Aero Sealed Switch Legacy	Honeywell	2
6PA67-4	Industrial Limit Switches	Honeywell	10
6PA78-4	Industrial Limit Switches	Honeywell	18
8A-2011	Subminiature Basics	Honeywell	25
8C-1011	Subminiature Basics	Honeywell	91
8C-1012	Subminiature Basics	Honeywell	743
8P-1021-007	Industrial Limit Switches	Honeywell	3
8P-2011-007	Industrial Limit Switches	Honeywell	100
8Z-0081	Switch	Honeywell	120
8Z-0082	Switch	Honeywell	250
8Z-0083	Switch	Honeywell	176
8Z0152	Switch	Honeywell	476
904-VB1-PG	Switch	Honeywell	45
908AS-2RQ8	Switch	Honeywell	7
918PA1-PG	Switch	Honeywell	1
935PA1	Industrial Limit Switches	Honeywell	10
9PA16-4	Industrial Limit Switches	Honeywell	4
9PA33-4	Industrial Limit Switches	Honeywell	4
AML-22CBJ3AD	Push Buttons	Honeywell	20
AML-31FBA4AC01	Push Buttons	Honeywell	8
AML-35FBC7AC01	Push Buttons	Honeywell	146
AML-36FBC4AC01	Push Buttons	Honeywell	147
AML-52C10Y	Push Buttons	Honeywell	30
AML-54F10K	Push Buttons	Honeywell	17
AML-55N10TK	Push Buttons	Honeywell	199
AML-56N10RK	Push Buttons	Honeywell	275
AML-56N10TK	Push Buttons	Honeywell	121

AT-10063W	Subminiature Basics	Honeywell	100
AWM2100V	Air Flow Sensor	Honeywell	1
AWM3100V	Air Flow Sensor	Honeywell	1
AWM5102VN	Air Flow Sensor	Honeywell	4
AWM5104VC	Air Flow Sensor	Honeywell	2
BA-2RV22-A2	Large Basic Switch	Honeywell	2
BAF3-2RN18-LHPG	Large Basic Switch	Honeywell	7
BZ-22RM-A2	Large Basic Switch	Honeywell	10
BZ-2G-A2	Large Basic Switch	Honeywell	1
BZ-2R	Large Basic Switch	Honeywell	2
BZ-2R-A2	Large Basic Switch	Honeywell	4
BZ-2R55-A2	Large Basic Switch	Honeywell	1
BZ-2RD	Large Basic Switch	Honeywell	10
BZ-2RL	Large Basic Switch	Honeywell	1
BZ-2RL-2	Large Basic Switch	Honeywell	1
BZ-2RM-A2	Large Basic Switch	Honeywell	2
BZ-2RQ-18-J	Large Basic Switch	Honeywell	190
BZ-2RQ1-T04	Large Basic Switch	Honeywell	1
BZ-2RQ18M	Large Basic Switch	Honeywell	1
BZ-2RS	Large Basic Switch	Honeywell	31
BZ-2RW-80	Large Basic Switch	Honeywell	66
BZ-2RW-82	Large Basic Switch	Honeywell	34
BZ-2RW-825	Large Basic Switch	Honeywell	31
BZ-2RW-826	Large Basic Switch	Honeywell	171
BZ-2RW-826-A2	Large Basic Switch	Honeywell	2
BZ-2RW-84	Large Basic Switch	Honeywell	93
BZ-2RW82-A2	Large Basic Switch	Honeywell	1
BZ-2RW825-A2	Large Basic Switch	Honeywell	119
BZ-2RW826	Large Basic Switch	Honeywell	9
BZ-2RW8299-A2	Large Basic Switch	Honeywell	1
BZ-2RW855-A2	Large Basic Switch	Honeywell	20
BZ-R-A2	Large Basic Switch	Honeywell	2
BZ-R19	Large Basic Switch	Honeywell	1
BZE7-2RQ8-PG	Large Basic Switch	Honeywell	21
BZE7-2RQ81-PG	Large Basic Switch	Honeywell	16
BZE7-2RQ9-PG	Large Basic Switch	Honeywell	2
CLSA1CH	Current Sensor	Honeywell	2
CSDA1BC	Current Sensor	Honeywell	2
CSLE4AD	Current Sensor	Honeywell	2
CSNH151	Current Sensor	Honeywell	10
CSNP661	Current Sensor	Honeywell	2
DT-2RV-22-A7	Large Basic Switch	Honeywell	49
DTF2-2RN-RH	Large Basic Switch	Honeywell	4
HAFBSF0200C2AX5	Air Flow Sensor	Honeywell	1
HC4-DC48V	Relay	Honeywell	299
HEL-705-T-0-12-00	Humidity Sensort	Honeywell	1
HIH-4031-001	Humidity Sensort	Honeywell	70
HMC1021Z	Mangentoresistive Sensor	Honeywell	1
HMC1051Z	Mangentoresistive Sensor	Honeywell	22
HMC1052	Mangentoresistive Sensor	Honeywell	1
HOA1404-002	Infrared Sensor	Honeywell	1
JE-1	Lever for switches	Honeywell	18
JE-5	Lever for switches	Honeywell	55
JS-2	Lever for switches	Honeywell	235
JS-2-C	Lever for switches	Honeywell	8
JS-220	Lever for switches	Honeywell	10
JS-246-C	Lever for switches	Honeywell	71
JS-31	Lever for switches	Honeywell	2
JS-33	Lever for switches	Honeywell	3
JS-5J	Lever for switches	Honeywell	3
JS-7	Lever for switches	Honeywell	58
JV-9020-C	Lever for switches	Honeywell	25
JX-20	Lever for switches	Honeywell	10

JX-206	Lever for switches	Honeywell	4
JX-4	Lever for switches	Honeywell	3
JX-47	Lever for switches	Honeywell	211
JX-95	Lever for switches	Honeywell	2
LML-2-S	Foot Switch	Honeywell	10
M922AA1Y-B4P-L	switch	Honeywell	1
M5594/1-2	Toggles & Rockers	Honeywell	5
M5594/1-3	Toggles & Rockers	Honeywell	22
MT-4RL2	Large Basic Switch	Honeywell	5
PC-10182	20PC option part	Honeywell	65
PC-10198	20PC option part	Honeywell	27
SS-12125	Hall Sensor	Honeywell	1
SS41	Hall Sensor	Honeywell	2
SS496A1	Hall Sensor	Honeywell	21
SS496A1-S	Hall Sensor	Honeywell	4
SS496A1-SP	Hall Sensor	Honeywell	4
SS94A1F	Hall Sensor	Honeywell	2
SSCDANN100MGAA3	PCB Pressure Sensor	Honeywell	2
SSCDANN100MGAA5	PCB Pressure Sensor	Honeywell	2
SSCSRNN400MGAA5	PCB Pressure Sensor	Honeywell	2
SSCSRNN400MGAA5	PCB Pressure Sensor	Honeywell	2
TD5A	Ptemperature Sensor	Honeywell	1
V3 9101M 11K	Micro Switch	Honeywell	1
V3 9101M-D18	Micro Switch	Honeywell	1
V3 9101M11-D18	Micro Switch	Honeywell	1
V3 9132M20	Micro Switch	Honeywell	1
V3 9245M	Micro Switch	Honeywell	2
V3 99128 M9 D18	Micro Switch	Honeywell	1
V3 99245M D18	Micro Switch	Honeywell	1
V3-101-D9	Micro Switch	Honeywell	1
V3-1101-D8	Micro Switch	Honeywell	39
V3-5000-S	Micro Switch	Honeywell	1
V3-5100	Micro Switch	Honeywell	1
V3-9001M-D18	Micro Switch	Honeywell	2
V3-9001M-F	Micro Switch	Honeywell	2
V3-9019M	Micro Switch	Honeywell	167
V3-9023M	Micro Switch	Honeywell	6
V3-9043	Micro Switch	Honeywell	1
V3-9101M-F	Micro Switch	Honeywell	9
V3-9115M	Micro Switch	Honeywell	613
V3-9115M11	Micro Switch	Honeywell	14
V309101M 11K	Micro Switch	Honeywell	1
V399246M	Micro Switch	Honeywell	4
V3L09101M11K	Micro Switch	Honeywell	1
V3L1122-D8	Micro Switch	Honeywell	3
V3LB9101M	Micro Switch	Honeywell	5
V3LD9101M20D18	Micro Switch	Honeywell	1
V3LE99123	Micro Switch	Honeywell	1
V4-14	Micro Switch	Honeywell	2
V5C010BB	Micro Switch	Honeywell	3
V5C010BB1D	Micro Switch	Honeywell	35
V7-3S17D8-048	Micro Switch	Honeywell	2
V91031CB	Micro Switch	Honeywell	6
V92031BB	Micro Switch	Honeywell	10
VR5C010BB3	Micro Switch	Honeywell	1
XN300736V3	XN300736V3	Honeywell	7
ZM50E70A01	XN300736V3	Honeywell	10
1HT1	High Temperature Switch	Honeywell	16
3HT1	High Temperature Switch	Honeywell	75
GMS10RVS	Oxygen Sensor	Honeywell	10
CH291-1220LF/T&R	Batteryholder / Batterycontact	Comfortable	10000
CH74-2032LF	Batteryholder / Batterycontact	Comfortable	10000
B318D	Batteryholder / Batterycontact	Comfortable	20000

B404B	Batteryholder / Batterycontact	Comfortable	500
BH131D	Batteryholder / Batterycontact	Comfortable	2400
BH432	Batteryholder / Batterycontact	Comfortable	30022
BS-IR-150	Batteryholder / Batterycontact	Comfortable	21500
BS-TR-150	Batteryholder / Batterycontact	Comfortable	4100
1LS1-4PGN159	Industrial Limit Switches	Honeywell	1
19C200PA1K	Pressure Sensor	Honeywell	3
400-2801-01-00-20	Batteryholder / Batterycontact	Cambion	750
400-1803-01-00-20	Batteryholder / Batterycontact	Cambion	250
400-2800-01-00-20	Batteryholder / Batterycontact	Cambion	350
BX0013-1	Batteryholder / Batterycontact	bulgin	572
BX0035	Batteryholder / Batterycontact	bulgin	100
BX0035AU	Batteryholder / Batterycontact	bulgin	100
43191679-002	Industry products	Honeywell-Fema	4
AF20-B65	Industry products	Honeywell-Fema	1
BA295CS-11/4A	Industry products	Honeywell-Fema	1
BA295S-1/2A	Industry products	Honeywell-Fema	1
D06FI-1B	Industry products	Honeywell-Fema	8
D06FN-1/2B	Industry products	Honeywell-Fema	2
DCM10-HNY	Industry products	Honeywell-Fema	2
DCM6	Industry products	Honeywell-Fema	28
DWR6	Industry products	Honeywell-Fema	4
DWR6-203	Industry products	Honeywell-Fema	2
ES06F-1/2A	Industry products	Honeywell-Fema	1
FK06-1/2AA	Industry products	Honeywell-Fema	1
KH11AS-1/2	Industry products	Honeywell-Fema	1
M07M-A4	Industry products	Honeywell-Fema	1
ML6421B3012	Industry products	Honeywell-Fema	3
N1024	Industry products	Honeywell-Fema	1
N2024-SW2	Industry products	Honeywell-Fema	2
S10230-2POS-SW2	Industry products	Honeywell-Fema	3
V5329C1018	Industry products	Honeywell-Fema	1
VNM111	Industry products	Honeywell-Fema	1
VSOE-215-1.6	Industry products	Honeywell-Fema	4
VST06-1/2A	Industry products	Honeywell-Fema	1
ZR06K	Industry products	Honeywell-Fema	1
C12000B	solder test point	Nicomatic	14000
25ET61-T	Aero Sealed Switch Legacy	Honeywell	1
10PA4	Large Basic Switch	Honeywell	1
111SM2-T	Subminiature Basics	Honeywell	45
11SM401-T	Subminiature Basics	Honeywell	760
11TW1-1L	Toggles & Rockers	Honeywell	44
11TW1-3	Toggles & Rockers	Honeywell	144
11TW1-3F	Toggles & Rockers	Honeywell	2
11TW1-8	Toggles & Rockers	Honeywell	69
120-103FAJ-Q01	thermostat	Honeywell	250
12SX2-T	Subminiature Basics	Honeywell	70
12TW1-10A	Toggles & Rockers	Honeywell	84
12TW1-1A	Toggles & Rockers	Honeywell	48
12TW1-3	Toggles & Rockers	Honeywell	132
12TW1-3F	Toggles & Rockers	Honeywell	86
12TW1-7	Toggles & Rockers	Honeywell	112
12TW1-70	Toggles & Rockers	Honeywell	102
12TW1-8	Toggles & Rockers	Honeywell	5
14CE18-6AH	Industrial Limit Switches	Honeywell	6
163-PC-01D75	Pressure Sensor	Honeywell	10
18PA1-4PG	Industrial Limit Switches	Honeywell	131
1HT1	High Temperature Switch	honeywell	138
3HT1	High Temperature Switch	Honywell	142
1LS1-4PG	High Temperature Switch	honeywell	3
1LS244-4PG	Industrial Limit Switches	Honeywell	25
1NT1-3	Toggles & Rockers	Honeywell	60
1NT1-4	Toggles & Rockers	Honeywell	23

1NT1-6	Toggles & Rockers	Honeywell	65
1NT1-7	Toggles & Rockers	Honeywell	145
1SE1-T	Subminiature Basics	Honeywell	600
1SX1-T	Subminiature Basics	Honeywell	4219
1XE1-3	Subminiature Basics	Honeywell	135
201LS2-4	Industrial Limit Switches	Honeywell	10
201LS3-4	Industrial Limit Switches	Honeywell	1
208LS1-4	Industrial Limit Switches	Honeywell	247
23SX39-T	Aero Sealed Switch Legacy	Honeywell	75
2455RM-90820468	thermostat	Honeywell	150
24CE31-Y1	Aero Sealed Switch Legacy	Honeywell	1
25ET61-S	Aero Sealed Switch Legacy	Honeywell	29
26PC01SMT	presseure sensor	Honeywell	5
26PC05SMT	Pressure Sensor	Honeywell	849
26PC15SMT	Pressure sensor	Honeywell	873
26PCAF2G	Pressure Sensor	Honeywell	50
26PCBFA6D	Pressure Sensor	Honeywell	15
26PCBFA6G	PCB pressure sensor	Honeywell	17
26PCBFM6G	PCB pressure sensor	Honeywell	68
26PCCFA6D	PCB pressure sensor	Honeywell	3
26PCCFA6G	PCB pressure sensor	Honeywell	28
26PCGFA2G	PCB pressure sensor	Honeywell	1200
2LS1-4PG	Industrial Limit Switches	Honeywell	24
2NT1-10	Toggles & Rockers	Honeywell	319
2NT1-3	Toggles & Rockers	Honeywell	48
2NT1-5N	Toggles & Rockers	Honeywell	25
2SS52M	hallsensor	Honeywell	284
311SM68-T	Subminiature Basics	Honeywell	65
4AV19F	hallsensor	Honeywell	136
5PA-PG9-1	Industrial Limit Switches	Honeywell	100
5PA2	Industrial Limit Switches	Honeywell	2
6HM1-1	Aero Sealed Switch Legacy	Honeywell	24
8LS1-4C	Industrial Limit Switches	Honeywell	15
8LS1-4PG	Industrial Limit Switches	Honeywell	6
91SS12-2	Hallsensor	Honeywell	223
9PA58-4	Industrial Limit Switches	Honeywell	4
ABPDANN005PG2A3	Basic Pressure Sensor	Honeywell	50
ABPDANT005PGAA5	Basic Pressure Sensor	Honeywell	30
ABPDANT015PGAA5	Basic Pressure Sensor	Honeywell	20
ABPDANT060PGAA5	Basic Pressure Sensor	Honeywell	40
ABPDJTT001PGAA5	Basic Pressure Sensor	Honeywell	5
ABPDLNN100MG2A3	Basic Pressure Sensor	Honeywell	15
ABPDRRT005PG2A5	Basic Pressure Sensor	Honeywell	43
ABPLLND060MGAA3	Basic Pressure Sensor	Honeywell	50
ABPLLNN015PG2D3	Basic Pressure Sensor	Honeywell	45
ABPLLNN600MGAA3	Basic Pressure Sensor	Honeywell	15
ABPLLNT010BGAA5	Basic Pressure Sensor	Honeywell	12
ABPMAND001PG2A3	Basic Pressure Sensor	Honeywell	10
ABPMANN004BGAA5	Basic Pressure Sensor	Honeywell	100
ABPMANN005PGAA3	Basic Pressure Sensor	Honeywell	50
ABPMANN030PG2A3	Basic Pressure Sensor	Honeywell	30
ABPMJJT015PGAA5	Basic Pressure Sensor	Honeywell	10
ABPMLNN001PGAA3	Basic Pressure Sensor	Honeywell	15
AWM2100V	Air Flow Sensor	Honeywell	65
AWM2300V	Air Flow Sensor	Honeywell	250
AWM3100V	Air Flow Sensor	Honeywell	82
AWM3150V	Air Flow Sensor	Honeywell	4
AWM3300V	Air Flow Sensor	Honeywell	149
AWM3303V	Air Flow Sensor	Honeywell	88
AWM42150VH	Air Flow Sensor	Honeywell	34
AWM43300V	Air Flow Sensor	Honeywell	152
AWM43600V	Air Flow Sensor	Honeywell	16
AWM5101VN	Air Flow Sensor	Honeywell	34

AWM5102VN	Air Flow Sensor	Honeywell	5
AWM5103VN	Air Flow Sensor	Honeywell	9
AWM5104VC	Air Flow Sensor	Honeywell	299
AWM5104VN	Air Flow Sensor	Honeywell	39
AWM720P1	Air Flow Sensor	Honeywell	68
BZ-2AW822T	Large Basic Switch	Honeywell	650
BZ-2RD-A2	Large Basic Switch	Honeywell	317
BZ-2RQ1-A2	Large Basic Switch	Honeywell	1395
BZ-2RQ13-A2	Large Basic Switch	Honeywell	400
BZ-2RQ18-A2	Large Basic Switch	Honeywell	731
BZ-2RW80-A2	Large Basic Switch	Honeywell	280
BZ-2RW82-A2	Large Basic Switch	Honeywell	200
BZ-2RW822-A2	Large Basic Switch	Honeywell	312
BZ-5RW822-A2-F2	Large Basic Switch	Honeywell	600
BZ-E7-2RN-C	Large Basic Switch	Honeywell	26
BZ-E7-2RN2-C	Large Basic Switch	Honeywell	2
BZ-R21	Large Basic Switch	Honeywell	211
BZE7-2RN-PG	Large Basic Switch	Honeywell	14
CPC30AFH	Pressure sensor	Honeywell	300
CSDA1BC	Current Sensor	Honeywell	37
CSLA1CD	Current Sensor	Honeywell	328
CSLA1CH	Current Sensor	Honeywell	24
CSNP661	Current Sensor	Honeywell	20
CSNS300M	Current Sensor	Honeywell	5
CSNX25	Current Sensor	Honeywell	15
FRN22212	pressure switch	Honeywell	205
FSG15N1A	force sensor	Honeywell	126
FSS015WNGB	force sensor	Honeywell	477
FSS1500NSB	force sensor	Honeywell	130
GLAC01A1B	Industrial Limit Switches	Honeywell	25
GLAC01C	Industrial Limit Switches	Honeywell	17
GLAC07A2B	Industrial Limit Switches	Honeywell	5
GLAC20C	Industrial Limit Switches	Honeywell	31
GLCC01A1A	Industrial Limit Switches	Honeywell	25
GLCC01A1B	Industrial Limit Switches	Honeywell	35
GLCC01A2B	Industrial Limit Switches	Honeywell	42
GLCC01C	Industrial Limit Switches	Honeywell	1
GLCC01E7B	Industrial Limit Switches	Honeywell	27
GLDC01A1A	Industrial Limit Switches	Honeywell	11
GLEB01A5B	Industrial Limit Switches	Honeywell	100
GXE51A1B	Industrial Limit Switches	Honeywell	30
HAFBSF0200C4AX3	Air Flow Sensor	Honeywell	110
HAFBSS0200C4AX3	Air Flow Sensor	Honeywell	1
HEL-705-T-0-12-00	Temperature Sensor	Honeywell	56
HEL-705-U-0-12-00	Temperature Sensor	Honeywell	90
HEL-707-T-0-12-00	Temperature Sensor	Honeywell	100
HEL-707-U-0-12-00	Temperature Sensor	Honeywell	125
HIH-4000-001	Humidity Sensor	Honeywell	135
HIH-4000-002	Humidity Sensor	Honeywell	1440
HIH-4010-001	Humidity Sensor	Honeywell	30
HIH-4010-002	Humidity Sensor	Honeywell	110
HIH-4010-004	Humidity Sensor	Honeywell	33
HIH-4020-001	Humidity Sensor	Honeywell	36
HIH-4020-002	Humidity Sensor	Honeywell	1
HIH-4020-004	Humidity Sensor	Honeywell	22
HIH-4021-001	Humidity Sensor	Honeywell	24
HIH-4021-002	Humidity Sensor	Honeywell	29
HIH-4021-004	Humidity Sensor	Honeywell	30
HIH-4030-001	Humidity Sensor	Honeywell	20
HIH-4031-001	Humidity Sensor	Honeywell	47
HIH-4602-L	Humidity Sensor	Honeywell	26
HIH-4602-L-CP	Humidity Sensor	Honeywell	5228
HIH-5030-001	Humidity Sensor	Honeywell	1070

HIH-5031-001	Humidity Sensor	Honeywell	759
HIH-6131-021-001	Humidity Sensor	Honeywell	32
HIH-7130-021-001	Humidity Sensor	Honeywell	50
HIH-7131-021-001	Humidity Sensor	Honeywell	21
HIH-8131-021-001	Humidity Sensor	Honeywell	70
HIH-9130-021-001	Humidity Sensor	Honeywell	55
HMC1021S	Magneto resistive sensor	Honeywell	10
HMC1021ZRC	Magneto resistive sensor	Honeywell	4
HMC1022	Magneto resistive sensor	Honeywell	137
HMC1051ZRC	Magneto resistive sensor	Honeywell	3
HOA1879-011	Infrared Sensor	Honeywell	46
HSCMANN1.6BA3A3	Pressure sensor	Honeywell	30
JS-151	Lever for switches	Honeywell	12
JS-5	Lever for switches	Honeywell	689
JV-5	Lever for switches	Honeywell	200
JX-42	Lever for switches	Honeywell	50
JX-51	Lever for switches	Honeywell	940
LLE101000	Lequid level sensor	Honeywell	21
LLE101101	Lequid level sensor	Honeywell	4
LLE102101	Lequid level sensor	Honeywell	130
LLE103101	Lequid level sensor	Honeywell	14
LLE105100	Lequid level sensor	Honeywell	5
LLE205100	Lequid level sensor	Honeywell	45
LLN865172-1	Lequid level sensor	Honeywell	16
LLN865172-2	Lequid level sensor	Honeywell	20
LM972-S	foot switch	Honeywell	94
LSYKC1ADD-8C-C	Industrial Limit Switches	Honeywell	10
LSZ3A	Industrial Limit Switches	Honeywell	5
MLT002N3000B5C/KONF	Potentiometer	Honeywell	1
MPRLS0025PA00001A	pression sensor	Honeywell	101
MPRLS0300YG00001B	Pressure sensor	Honeywell	180
NGCMA50AX32A1A	Industrial Limit Switches	Honeywell	3
NGCMB10AX01C	Industrial Limit Switches	Honeywell	1
NGCMB10AX01A1A	Industrial Limit Switches	Honeywell	4
NGCPA10AX01A1A	Industrial Limit Switches	Honeywell	4
NGCPA10AX01B	Industrial Limit Switches	Honeywell	4
NGCPA10AX01C	Industrial Limit Switches	Honeywell	4
NGCPA50AX32A1A	Industrial Limit Switches	Honeywell	9
NGCPA50AX32B	Industrial Limit Switches	Honeywell	8
NGCPA50AX32C	Industrial Limit Switches	Honeywell	9
NGCPA50AX32L	Industrial Limit Switches	Honeywell	9
NGCPB10AX01B	Industrial Limit Switches	Honeywell	1
NGCPB10AX01L	Industrial Limit Switches	Honeywell	1
RTY090HVEAX	Angle sensor	Honeywell	45
RTY180HVEAX	Angle sensor	Honeywell	24
RTY270HVEAX	Angle sensor	Honeywell	50
RTY360HVEAX	Angle sensor	Honeywell	59
SCX030DNC	pression sensor	Honeywell	200
SCX05DNC	Pressure sensor	Honeywell	269
SCX150DNC	Pressure sensor	Honeywell	250
SCX30ANC	Pressure sensor	Honeywell	51
SCXL004DN	Pressure sensor	Honeywell	1
SDX010IND4	Pressure sensor	Honeywell	125
SDX05D4	Pressure sensor	Honeywell	200
SDX100A2	Pressure sensor	Honeywell	35
SDX30A4	Pressure sensor	Honeywell	173
SDX30D4	Pressure sensor	Honeywell	50
SE1470-003L	Infrared Sensor	Honeywell	57
SEK001	demo board	Honeywell	9
SEK002	demo board	Honeywell	8
SEP8506-003	Infrared Sensor	Honeywell	200
SEP8706-003	Infrared Sensor	Honeywell	877
SM351LT	Hallsensor	Honeywell	250

SPS-A100D-HAMS	Angle sensor	Honeywell	3
SPS-R360D_5PIN_PLUG	Angle sensor	Honeywell	12
SR17C-J6	Hallsensor	Honeywell	230
SS-461A	Hallsensor	Honeywell	2036
SS41	Hallsensor	Honeywell	2705
SS411A	Hallsensor	Honeywell	749
SS413A	Hallsensor	Honeywell	7850
SS441A	Hallsensor	Honeywell	1094
SS443A	Hallsensor	Honeywell	591
SS495A	Hallsensor	Honeywell	750
SS495A-SP	Hallsensor	Honeywell	750
SS495A1	Hallsensor	Honeywell	1715
SS543AT	Hallsensor	Honeywell	508
SS549AT	Hallsensor	Honeywell	765
SS59ET	Hallsensor	Honeywell	596
SS94A1	Hallsensor	Honeywell	314
SS94A2	Hallsensor	Honeywell	110
SSCDRRN004NDAA5	presseure sensor	Honeywell	6
SSCSAAN004ND2A5	Pressure sensor	Honeywell	275
SSCSHNN030PAAA5	Pressure sensor	Keystone	1000
TBPLLNN015PGUCV	Pressure sensor	Keystone	100
V15W11-WZ200A02-W2	Micro Switch	Keystone	700
V15W11-WZ200A04-W3	Micro Switch	Keystone	275
1012	Batteryholder / Batterycontact	Keystone	6
1018	Batteryholder / Batterycontact	Keystone	778
1020	Batteryholder / Batterycontact	Keystone	155
1022KEY	Batteryholder / Batterycontact	Keystone	100
1024	Batteryholder / Batterycontact	Keystone	813
1025	Batteryholder / Batterycontact	Keystone	445
1025-7	Batteryholder / Batterycontact	Keystone	2600
1027	Batteryholder / Batterycontact	Keystone	93
1028	Batteryholder / Batterycontact	Keystone	3648
1028 C	Batteryholder / Batterycontact	Keystone	7251
1029	Batteryholder / Batterycontact	Keystone	2116
1029 C	Batteryholder / Batterycontact	Keystone	1040
1029LC	Batteryholder / Batterycontact	Keystone	4950
103	Batteryholder / Batterycontact	Keystone	8395
1033	Batteryholder / Batterycontact	Keystone	95
1042	Batteryholder / Batterycontact	Keystone	574
1042P	Batteryholder / Batterycontact	Keystone	62
1043	Batteryholder / Batterycontact	Keystone	123
1043P	Batteryholder / Batterycontact	Keystone	99
1044	Batteryholder / Batterycontact	Keystone	100
1047	Batteryholder / Batterycontact	Keystone	460
1048	Batteryholder / Batterycontact	Keystone	80
1049	Batteryholder / Batterycontact	Keystone	23
105	Batteryholder / Batterycontact	Keystone	971
1053	Batteryholder / Batterycontact	Keystone	20
1056TR	Batteryholder / Batterycontact	Keystone	3
1058	Batteryholder / Batterycontact	Keystone	50
1059	Batteryholder / Batterycontact	Keystone	1160
106	Batteryholder / Batterycontact	Keystone	7117
1060	Batteryholder / Batterycontact	Keystone	98
1061	Batteryholder / Batterycontact	Keystone	1771
1065	Batteryholder / Batterycontact	Keystone	289
1066	Batteryholder / Batterycontact	Keystone	4181
1067	Batteryholder / Batterycontact	Keystone	511
1068	Batteryholder / Batterycontact	Keystone	525
1069	Batteryholder / Batterycontact	Keystone	75
107	Batteryholder / Batterycontact	Keystone	493
1070	Batteryholder / Batterycontact	Keystone	558
108	Batteryholder / Batterycontact	Keystone	7405
108-2	Batteryholder / Batterycontact	Keystone	13371

108-C	Batteryholder / Batterycontact	Keystone	10078
1081	Batteryholder / Batterycontact	Keystone	18
1087	Batteryholder / Batterycontact	Keystone	5
1089	Batteryholder / Batterycontact	Keystone	2
109-3	Batteryholder / Batterycontact	Keystone	2
1090	Batteryholder / Batterycontact	Keystone	2
1095P	Batteryholder / Batterycontact	Keystone	73
1096P	Batteryholder / Batterycontact	Keystone	115
1097	Batteryholder / Batterycontact	Keystone	50
1097P	Batteryholder / Batterycontact	Keystone	25
1098	Batteryholder / Batterycontact	Keystone	80
1098P	Batteryholder / Batterycontact	Keystone	20
1101	Batteryholder / Batterycontact	Keystone	80
1102	Batteryholder / Batterycontact	Keystone	25
1106	Batteryholder / Batterycontact	Keystone	75
1107	Batteryholder / Batterycontact	Keystone	51
1108	Batteryholder / Batterycontact	Keystone	48
1109	Batteryholder / Batterycontact	Keystone	50
1114	Batteryholder / Batterycontact	Keystone	2
112	Batteryholder / Batterycontact	Keystone	2618
117-LABEL	Batteryholder / Batterycontact	Keystone	509
120	Batteryholder / Batterycontact	Keystone	80
122TR	Batteryholder / Batterycontact	Keystone	2000
1294	Batteryholder / Batterycontact	Keystone	1200
1295	Batteryholder / Batterycontact	Keystone	1100
138	Batteryholder / Batterycontact	Keystone	101
146	Batteryholder / Batterycontact	Keystone	80
147	Batteryholder / Batterycontact	Keystone	20
148	Batteryholder / Batterycontact	Keystone	10
149	Batteryholder / Batterycontact	Keystone	60
151	Batteryholder / Batterycontact	Keystone	76
152	Batteryholder / Batterycontact	Keystone	28
158	Batteryholder / Batterycontact	Keystone	40
175	Batteryholder / Batterycontact	Keystone	404
202	Batteryholder / Batterycontact	Keystone	6526
204	Batteryholder / Batterycontact	Keystone	12688
209	Batteryholder / Batterycontact	Keystone	19399
210	Batteryholder / Batterycontact	Keystone	10000
211	Batteryholder / Batterycontact	Keystone	43
211 D	Batteryholder / Batterycontact	Keystone	950
2239	Batteryholder / Batterycontact	Keystone	100
2242	Batteryholder / Batterycontact	Keystone	100
228	Batteryholder / Batterycontact	Keystone	1000
230-1	Batteryholder / Batterycontact	Keystone	50
238	Batteryholder / Batterycontact	Keystone	6027
2413	Batteryholder / Batterycontact	Keystone	20
2460RB	Batteryholder / Batterycontact	Keystone	500
2468	Batteryholder / Batterycontact	Keystone	153
261	Batteryholder / Batterycontact	Keystone	131
269	Batteryholder / Batterycontact	Keystone	16
288	Batteryholder / Batterycontact	Keystone	900
290	Batteryholder / Batterycontact	Keystone	1291
291	Batteryholder / Batterycontact	Keystone	494
2915	Batteryholder / Batterycontact	Keystone	3
295	Batteryholder / Batterycontact	Keystone	2805
296	Batteryholder / Batterycontact	Keystone	1615
2982	Batteryholder / Batterycontact	Keystone	82
2988	Batteryholder / Batterycontact	Keystone	2
299	Batteryholder / Batterycontact	Keystone	2
2990	Batteryholder / Batterycontact	Keystone	920
2991	Batteryholder / Batterycontact	Keystone	6810
2991TR	Batteryholder / Batterycontact	Keystone	1500
2992TR	Batteryholder / Batterycontact	Keystone	395

2994	Batteryholder / Batterycontact	Keystone	2
2996	Batteryholder / Batterycontact	Keystone	1968
2998	Batteryholder / Batterycontact	Keystone	557
2999	Batteryholder / Batterycontact	Keystone	2017
3000	Batteryholder / Batterycontact	Keystone	276
3001	Batteryholder / Batterycontact	Keystone	72
3002	Batteryholder / Batterycontact	Keystone	53
3002TR	Batteryholder / Batterycontact	Keystone	10000
3003	Batteryholder / Batterycontact	Keystone	8932
3005	Batteryholder / Batterycontact	Keystone	1400
3006TR	Batteryholder / Batterycontact	Keystone	1200
3008	Batteryholder / Batterycontact	Keystone	803
3008TR	Batteryholder / Batterycontact	Keystone	3000
3009	Batteryholder / Batterycontact	Keystone	188
3012	Batteryholder / Batterycontact	Keystone	5409
3013	Batteryholder / Batterycontact	Keystone	3
3020	Batteryholder / Batterycontact	Keystone	208
3022	Batteryholder / Batterycontact	Keystone	100
3026	Batteryholder / Batterycontact	Keystone	102
3027	Batteryholder / Batterycontact	Keystone	1032
3030	Batteryholder / Batterycontact	Keystone	2
3030TR	Batteryholder / Batterycontact	Keystone	4
3517	Batteryholder / Batterycontact	Keystone	844
4814	Batteryholder / Batterycontact	Keystone	5000
500	Batteryholder / Batterycontact	Keystone	6850
5001	Batteryholder / Batterycontact	Keystone	1336
5004	Batteryholder / Batterycontact	Keystone	2
5006	Batteryholder / Batterycontact	Keystone	3590
5007	Batteryholder / Batterycontact	Keystone	23000
5011	Batteryholder / Batterycontact	Keystone	500
5016	Batteryholder / Batterycontact	Keystone	2002
5017	Batteryholder / Batterycontact	Keystone	25
502	Batteryholder / Batterycontact	Keystone	4859
5201	Batteryholder / Batterycontact	Keystone	23744
5202	Batteryholder / Batterycontact	Keystone	14240
5203	Batteryholder / Batterycontact	Keystone	4767
5204	Batteryholder / Batterycontact	Keystone	16434
5208	Batteryholder / Batterycontact	Keystone	5000
5209	Batteryholder / Batterycontact	Keystone	10
5212	Batteryholder / Batterycontact	Keystone	4000
5213	Batteryholder / Batterycontact	Keystone	963
5214	Batteryholder / Batterycontact	Keystone	1740
5218	Batteryholder / Batterycontact	Keystone	5
5219	Batteryholder / Batterycontact	Keystone	2
5220	Batteryholder / Batterycontact	Keystone	2
5221	Batteryholder / Batterycontact	Keystone	50555
5222	Batteryholder / Batterycontact	Keystone	50000
5223	Batteryholder / Batterycontact	Keystone	39
5224	Batteryholder / Batterycontact	Keystone	8259
5225	Batteryholder / Batterycontact	Keystone	3310
5226	Batteryholder / Batterycontact	Keystone	11551
5230	Batteryholder / Batterycontact	Keystone	341
5231	Batteryholder / Batterycontact	Keystone	10635
5231TR	Batteryholder / Batterycontact	Keystone	6000
54/18650	Batteryholder / Batterycontact	Keystone	600
55	Batteryholder / Batterycontact	Keystone	2
56TR	Batteryholder / Batterycontact	Keystone	2500
57	Batteryholder / Batterycontact	Keystone	5977
590	Batteryholder / Batterycontact	Keystone	4318
591	Batteryholder / Batterycontact	Keystone	7882
593	Batteryholder / Batterycontact	Keystone	371
594	Batteryholder / Batterycontact	Keystone	500
595	Batteryholder / Batterycontact	Keystone	3385

596	Batteryholder / Batterycontact	Keystone	2
628	Batteryholder / Batterycontact	Keystone	1819
629	Batteryholder / Batterycontact	Keystone	2206
635	Batteryholder / Batterycontact	Keystone	3
7143	Batteryholder / Batterycontact	Keystone	54
7170	Batteryholder / Batterycontact	Keystone	42
82	Batteryholder / Batterycontact	Keystone	19988
9-5230-191	Batteryholder / Batterycontact	Keystone	13167
92	Batteryholder / Batterycontact	Keystone	7244
967	Batteryholder / Batterycontact	Keystone	50
968	Batteryholder / Batterycontact	Keystone	1272
C-14862-SOM	Batteryholder / Batterycontact	Keystone	6600
CH291-1220LF/T&R	Batteryholder / Batterycontact	Comfortable	22000
CH25-2032LF	Batteryholder / Batterycontact	Comfortable	23000
BH 432	Batteryholder / Batterycontact	Comfortable	22022
BS-IR-150	Batteryholder / Batterycontact	Comfortable	19500
ABG-43	Batteryholder / Batterycontact	MPD	3
ABG-44	Batteryholder / Batterycontact	MPD	5
BA2032SM	Batteryholder / Batterycontact	MPD	1154
BA3AAPC-UL94V-0	Batteryholder / Batterycontact	MPD	180
BA4AAPC-UL94V-0	Batteryholder / Batterycontact	MPD	100
BC1/3N-C-SM	Batteryholder / Batterycontact	MPD	800
BC3AAPC	Batteryholder / Batterycontact	MPD	99
BC4AAW	Batteryholder / Batterycontact	MPD	114
BC501SM	Batteryholder / Batterycontact	MPD	3
BH 1/3N-C	Batteryholder / Batterycontact	MPD	9306
BH 2N	Batteryholder / Batterycontact	MPD	1686
BH18650-W	Batteryholder / Batterycontact	MPD	455
BH212DW	Batteryholder / Batterycontact	MPD	60
BH26AASF	Batteryholder / Batterycontact	MPD	541
BH26DW	Batteryholder / Batterycontact	MPD	97
BH28DL	Batteryholder / Batterycontact	MPD	2
BH2AAAW	Batteryholder / Batterycontact	MPD	110
BH2AAW	Batteryholder / Batterycontact	MPD	240
BH2DW	Batteryholder / Batterycontact	MPD	4700
BH32T-C	Batteryholder / Batterycontact	MPD	4760
BH3AAW	Batteryholder / Batterycontact	MPD	200
BH3DW	Batteryholder / Batterycontact	MPD	200
BH48DW	Batteryholder / Batterycontact	MPD	56
BHD-2	Batteryholder / Batterycontact	MPD	106
BLP2032SM-GTR	Batteryholder / Batterycontact	MPD	600
B55 VERTICAL	Batteryholder / Batterycontact	MPD	1500
LP2032SM-JJ-GTR	Batteryholder / Batterycontact	MPD	6
MBHCW	Batteryholder / Batterycontact	MPD	147
BCC	Batteryholder / Batterycontact	MPD	700
BK885	Batteryholder / Batterycontact	MPD	1632
ABG-43	Batteryholder / Batterycontact	MPD	53
ABG-44	Batteryholder / Batterycontact	MPD	50
BA2AAPC	Batteryholder / Batterycontact	MPD	50
BA3AAW	Batteryholder / Batterycontact	MPD	250
BA4AAW	Batteryholder / Batterycontact	MPD	745
BA4D-S	Batteryholder / Batterycontact	MPD	50
BC-2003	Batteryholder / Batterycontact	MPD	2000
BC2032-E2	Batteryholder / Batterycontact	MPD	100
BC22AAW	Batteryholder / Batterycontact	MPD	300
BC2AAAPC	Batteryholder / Batterycontact	MPD	2354
BC2AAAW	Batteryholder / Batterycontact	MPD	700
BC2AAPC	Batteryholder / Batterycontact	MPD	1000
BC2AAW	Batteryholder / Batterycontact	MPD	50
BC34AASF	Batteryholder / Batterycontact	MPD	5
BC3AAAW	Batteryholder / Batterycontact	MPD	200
BC4AAAW	Batteryholder / Batterycontact	MPD	70
BC4AAB	Batteryholder / Batterycontact	MPD	3078

BC501SMTR	Batteryholder / Batterycontact	MPD	3000
BCAA	Batteryholder / Batterycontact	MPD	1708
BCAAAPC	Batteryholder / Batterycontact	MPD	300
BCAAAW	Batteryholder / Batterycontact	MPD	200
BCAAW	Batteryholder / Batterycontact	MPD	140
BH1000G	Batteryholder / Batterycontact	MPD	100
BH123A	Batteryholder / Batterycontact	MPD	30004
BH13CW	Batteryholder / Batterycontact	MPD	75
BH14AASF	Batteryholder / Batterycontact	MPD	302
BH16AAL	Batteryholder / Batterycontact	MPD	10
BH16AAW	Batteryholder / Batterycontact	MPD	10
BH210CL	Batteryholder / Batterycontact	MPD	30
BH210CW	Batteryholder / Batterycontact	MPD	110
BH223L	Batteryholder / Batterycontact	MPD	120
BH22CL	Batteryholder / Batterycontact	MPD	601
BH24AASF	Batteryholder / Batterycontact	MPD	306
BH26CW	Batteryholder / Batterycontact	MPD	35
BH28AAAW	Batteryholder / Batterycontact	MPD	200
BH2CL	Batteryholder / Batterycontact	MPD	100
BH2CW	Batteryholder / Batterycontact	MPD	70
BH2NW	Batteryholder / Batterycontact	MPD	150
BH3000	Batteryholder / Batterycontact	MPD	150
BH48CW	Batteryholder / Batterycontact	MPD	40
BH4CW	Batteryholder / Batterycontact	MPD	80
BH4NW	Batteryholder / Batterycontact	MPD	100
BH600	Batteryholder / Batterycontact	MPD	600
BH600-5.8-G	Batteryholder / Batterycontact	MPD	840
BH600-G	Batteryholder / Batterycontact	MPD	1000
BH908T-C	Batteryholder / Batterycontact	MPD	4000
BH9VW	Batteryholder / Batterycontact	MPD	410
BHAA-3-G	Batteryholder / Batterycontact	MPD	3
BHAA-POL	Batteryholder / Batterycontact	MPD	200
BHC-2	Batteryholder / Batterycontact	MPD	148
BHC-POL	Batteryholder / Batterycontact	MPD	29
BHSD-2032-L	Batteryholder / Batterycontact	MPD	20
BHSD1225COVER	Batteryholder / Batterycontact	MPD	1526
BHSD1225SM	Batteryholder / Batterycontact	MPD	1524
BHX1-1632-SCHUB	Batteryholder / Batterycontact	MPD	148
BHX1-2032-SM	Batteryholder / Batterycontact	MPD	887
BI-2032	Batteryholder / Batterycontact	MPD	15030
BI-UM-1-2	Batteryholder / Batterycontact	MPD	695
BI-UM-3-4	Batteryholder / Batterycontact	MPD	4500
BK-030	Batteryholder / Batterycontact	MPD	445
BK-1264-PC8	Batteryholder / Batterycontact	MPD	50
BK-1280-PC6	Batteryholder / Batterycontact	MPD	100
BK-18650-PC4	Batteryholder / Batterycontact	MPD	675
BK-18650-PC6	Batteryholder / Batterycontact	MPD	265
BK-18650-PC8	Batteryholder / Batterycontact	MPD	508
BK-204	Batteryholder / Batterycontact	MPD	20
BK-209	Batteryholder / Batterycontact	MPD	789
BK-228	Batteryholder / Batterycontact	MPD	720
BK-5058	Batteryholder / Batterycontact	MPD	200
BK-5091	Batteryholder / Batterycontact	MPD	500
BK-6049	Batteryholder / Batterycontact	MPD	17
BK-6113	Batteryholder / Batterycontact	MPD	6
BK-868	Batteryholder / Batterycontact	MPD	48
BK-870	Batteryholder / Batterycontact	MPD	5
BK-874	Batteryholder / Batterycontact	MPD	1201
BK-875	Batteryholder / Batterycontact	MPD	1234
BK-876	Batteryholder / Batterycontact	MPD	1200
BK-880	Batteryholder / Batterycontact	MPD	1200
BK-883	Batteryholder / Batterycontact	MPD	660
BK-883-TR	Batteryholder / Batterycontact	MPD	900

BK-885	Batteryholder / Batterycontact	MPD	5
BK-885-TR	Batteryholder / Batterycontact	MPD	2400
BK-888	Batteryholder / Batterycontact	MPD	399
BK-912	Batteryholder / Batterycontact	MPD	258
BK-912TR	Batteryholder / Batterycontact	MPD	16800
BK-913	Batteryholder / Batterycontact	MPD	10000
BK-92	Batteryholder / Batterycontact	MPD	20500
BLP2016SM-GTR	Batteryholder / Batterycontact	MPD	20
BRX1-2032-SM-TR	Batteryholder / Batterycontact	MPD	9000
BS1225-PC	Batteryholder / Batterycontact	MPD	27100
BS2450	Batteryholder / Batterycontact	MPD	1500
BS3	Batteryholder / Batterycontact	MPD	900
BSF	Batteryholder / Batterycontact	MPD	2058
BSM	Batteryholder / Batterycontact	MPD	2089
BSR	Batteryholder / Batterycontact	MPD	438
BU1-M-402	Batteryholder / Batterycontact	MPD	50
BU2032-1-HD-G	Batteryholder / Batterycontact	MPD	370
BU2032SM	Batteryholder / Batterycontact	MPD	5
BU2032SM-BT-GTR	Batteryholder / Batterycontact	MPD	6400
BU2032SM-G	Batteryholder / Batterycontact	MPD	14400
BU2032SM-HD-G	Batteryholder / Batterycontact	MPD	1200
BU2032SM-JJ	Batteryholder / Batterycontact	MPD	300
BU2032SM-JJ-GTR	Batteryholder / Batterycontact	MPD	3760
BU2450SM-JJ-GTR	Batteryholder / Batterycontact	MPD	4250
BV1632-G	Batteryholder / Batterycontact	MPD	5100
BVSD-2032-COVER	Batteryholder / Batterycontact	MPD	20
BVSD-2032-PC	Batteryholder / Batterycontact	MPD	40
CB-AA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AA-PC-POS	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-POS	Batteryholder / Batterycontact	MPD	120
ZA5350	Batteryholder / Batterycontact	MPD	30
ZA5350-B	Batteryholder / Batterycontact	MPD	450