

Rossmann Electronic GMBH GERMANY		stocklist:	
<a href="http://www.rossmannweb.de">www.rossmannweb.de</a>	FON: 0049 8807-94994-0	dated	
<a href="mailto:info@rossmannweb.de">info@rossmannweb.de</a>	FAX: 0049 8807-94994-29	06.02.2019	
Item:	Description:	Mfq.:	stock - items:
1012C	Batteryholder / Batterycontact	Keystone	12
1018	Batteryholder / Batterycontact	Keystone	778
1027	Batteryholder / Batterycontact	Keystone	93
1029 C	Cover for 1029	Keystone	1040
1029LC	Cover for 1029	Keystone	4950
1044	Batteryholder / Batterycontact	Keystone	100
1053	Batteryholder / Batterycontact	Keystone	20
1056TR	Batteryholder / Batterycontact	Keystone	3
1059	Batteryholder / Batterycontact	Keystone	1160
1066	Batteryholder / Batterycontact	Keystone	4384
1081	Batteryholder / Batterycontact	Keystone	18
1089	Batteryholder / Batterycontact	Keystone	2
1090	Batteryholder / Batterycontact	Keystone	2
1096P	Batteryholder / Batterycontact	Keystone	115
1097	Batteryholder / Batterycontact	Keystone	50
1097P	Batteryholder / Batterycontact	Keystone	25
1098	Batteryholder / Batterycontact	Keystone	80
1098P	Batteryholder / Batterycontact	Keystone	20
1102	Batteryholder / Batterycontact	Keystone	50
1114	Batteryholder / Batterycontact	Keystone	2
120	Batteryholder / Batterycontact	Keystone	80
122TR	Batteryholder / Batterycontact	Keystone	2000
138	Batteryholder / Batterycontact	Keystone	101
149	Batteryholder / Batterycontact	Keystone	60
151	Batteryholder / Batterycontact	Keystone	76
230-1	Batteryholder / Batterycontact	Keystone	50
2413	Captive Screw	Keystone	20
2460RB	Batteryholder / Batterycontact	Keystone	500
2468	Batteryholder / Batterycontact	Keystone	153
2482	Batteryholder / Batterycontact	Keystone	1
2490	Batteryholder / Batterycontact	Keystone	2
269	Batteryholder / Batterycontact	Keystone	16
288	Batteryholder / Batterycontact	Keystone	1095
2915	Batteryholder / Batterycontact	Keystone	3
2990	Batteryholder / Batterycontact	Keystone	920
2991	Batteryholder / Batterycontact	Keystone	6810
2996	Batteryholder / Batterycontact	Keystone	1968
2998	Batteryholder / Batterycontact	Keystone	557
3001	Batteryholder / Batterycontact	Keystone	72
3005	Batteryholder / Batterycontact	Keystone	1400
3006TR	Batteryholder / Batterycontact	Keystone	1200
3008	Batteryholder / Batterycontact	Keystone	803
3009	Batteryholder / Batterycontact	Keystone	188
3020	Batteryholder / Batterycontact	Keystone	208
3026	Batteryholder / Batterycontact	Keystone	102
3027	Batteryholder / Batterycontact	Keystone	1032
3096	Batteryholder / Batterycontact	Keystone	-2
400-2802-01-00-20	Batteryholder / Batterycontact	Cambion	250
4814	Nylon Stand	Keystone	6000
482	Handle	Keystone	59
5004	Test Point	Keystone	2
5202	Batteryholder / Batterycontact	Keystone	14245
5203	Batteryholder / Batterycontact	Keystone	5030
5209	Batteryholder / Batterycontact	Keystone	10
5213	Batteryholder / Batterycontact	Keystone	217
5214	Batteryholder / Batterycontact	Keystone	1740
5218	Batteryholder / Batterycontact	Keystone	5
5221	Batteryholder / Batterycontact	Keystone	665

5224	Batteryholder / Batterycontact	Keystone	8264
56TR	Batteryholder / Batterycontact	Keystone	2500
591	Batteryholder / Batterycontact	Keystone	7882
635	Batteryholder / Batterycontact	Keystone	3
7170	Handle	Keystone	42
b	Batteryholder / Batterycontact	Keystone	50
ABG-43	Battery Clip	MPD	3
BC1/3N-C-SM	Batteryholder / Batterycontact	MPD	800
BC3AAPC	Batteryholder / Batterycontact	MPD	99
BC501SM	Batteryholder / Batterycontact	MPD	3
BH212DW	Batteryholder / Batterycontact	MPD	60
BH28DL	Batteryholder / Batterycontact	MPD	2
BH2DW	Batteryholder / Batterycontact	MPD	60
BH3AAW	Batteryholder / Batterycontact	MPD	200
BHD-2	Batteryholder / Batterycontact	MPD	206
MBHCW	Batteryholder / Batterycontact	MPD	147
BCC	Batteryholder / Batterycontact	MPD	700
BK885	Batteryholder / Batterycontact	MPD	2632
ABG-44	Battery Clip	MPD	50
BC2032-E2	Batteryholder / Batterycontact	MPD	100
BC2AAAW	Batteryholder / Batterycontact	MPD	700
BC34AASF	Batteryholder / Batterycontact	MPD	5
BC4AAAW	Batteryholder / Batterycontact	MPD	120
BC501SMTR	Batteryholder / Batterycontact	MPD	500
BCAA	Batteryholder / Batterycontact	MPD	1708
BCAAAPC	Batteryholder / Batterycontact	MPD	300
BH13CW	Batteryholder / Batterycontact	MPD	150
BH16AAW	Batteryholder / Batterycontact	MPD	10
BH210CL	Batteryholder / Batterycontact	MPD	50
BH2AAAPC	Batteryholder / Batterycontact	MPD	5
BH2CL	Batteryholder / Batterycontact	MPD	100
BH2CW	Batteryholder / Batterycontact	MPD	100
BH2NW	Batteryholder / Batterycontact	MPD	150
BH4CW	Batteryholder / Batterycontact	MPD	80
BHAA-POL	Batteryholder / Batterycontact	MPD	200
BHDW	Batteryholder / Batterycontact	MPD	100
BHSD-2032-L	Batteryholder / Batterycontact	MPD	20
BHX1-1632-SM	Batteryholder / Batterycontact	MPD	937
BK-204	Batteryholder / Batterycontact	MPD	20
BK-209	Batteryholder / Batterycontact	MPD	790
BK-228	Batteryholder / Batterycontact	MPD	720
BK-5091	Batteryholder / Batterycontact	MPD	500
BK-868	Batteryholder / Batterycontact	MPD	48
BK-870	Batteryholder / Batterycontact	MPD	5
BK-883	Batteryholder / Batterycontact	MPD	660
BK-885	Batteryholder / Batterycontact	MPD	5
BK-912	Batteryholder / Batterycontact	MPD	258
BK-1279	Batteryholder / Batterycontact	MPD	8
BLP2016SM-GTR	Batteryholder / Batterycontact	MPD	20
BSR	Batteryholder / Batterycontact	MPD	2420
BU2032SM	Batteryholder / Batterycontact	MPD	5
BU2450SM-JJ-GTR	Batteryholder / Batterycontact	MPD	4250
BVSD-2032-COVER	Batteryholder / Batterycontact	MPD	20
BVSD-2032-PC	Batteryholder / Batterycontact	MPD	40
CB-AA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AA-PC-POS	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-POS	Batteryholder / Batterycontact	MPD	120
392 SONY	Coin Cell	Sony	8
395 SONY	Coin Cell	Sony	30
CR 2032 PANASONIC	Coin Cell	Panasonic	15
CR 2032 VARTA	Coin Cell	Varta	300
CR 2032BLISTER	Coin Cell	Varta	45

CR1620 SONY	Coin Cell	Sony	500
CR2450HT RENATA	Coin Cell	Renata	105
CR3032	Coin Cell	Panasonic	220
ER14505 / EVE	Coin Cell	EVE	10
AAA ENELOOP NIMH BUL	Battery	Eneloop	1000
LR03/AAA/PROCELL/10P	Battery	Duracell	20
LR20 PROCELL	Battery	Duracell	30
LR6/PROCELL	Battery	Duracell	155
CDRH6D23HP	inductive component	SUMIDA	2000
1RA1	switch	Honeywell	2
1PB5-T	Push Buttons	Honeywell	1
111SM2-T	Subminiature Basics	Honeywell	4
311SM6-T	Subminiature Basics	Honeywell	1
311SM1-T	Subminiature Basics	Honeywell	10
11SM3-S	Subminiature Basics	Honeywell	1
11SM1-N102	Subminiature Basics	Honeywell	6
111SM1-T	Subminiature Basics	Honeywell	3
311SM701-T	Subminiature Basics	Honeywell	2
311SM7604-H4	Subminiature Basics	Honeywell	3
311SM5-T	Subminiature Basics	Honeywell	5
311SM1-H2	Subminiature Basics	Honeywell	1
311SM702-T	Subminiature Basics	Honeywell	5
11SM23-H58	Subminiature Basics	Honeywell	3
311SM201	Subminiature Basics	Honeywell	3
311SM4-T	Subminiature Basics	Honeywell	6
311SM1	Subminiature Basics	Honeywell	2
311SM56	Subminiature Basics	Honeywell	1
311SM2-T	Subminiature Basics	Honeywell	1
311SX4-T	Subminiature Basics	Honeywell	1
11SM1	Subminiature Basics	Honeywell	10
1SM22	Subminiature Basics	Honeywell	5
411SM1	Subminiature Basics	Honeywell	2
11SM701-T	Subminiature Basics	Honeywell	5
1SM2-T	Subminiature Basics	Honeywell	5
11SM3-T	Subminiature Basics	Honeywell	3
41SM1-T	Subminiature Basics	Honeywell	3
11SM1-T24	Subminiature Basics	Honeywell	5
11SM244-T	Subminiature Basics	Honeywell	1
313SX2-T	Subminiature Basics	Honeywell	2
103MG5	Subminiature Basics	Honeywell	2
11SM23-T	Subminiature Basics	Honeywell	1338
11SM243-T	Subminiature Basics	Honeywell	45
11SM701-T	Subminiature Basics	Honeywell	75
11SX21-T	Subminiature Basics	Honeywell	2
12SM4-T	Subminiature Basics	Honeywell	359
12SX3-T	Subminiature Basics	Honeywell	175
1LS19-4PG	Industrial Limit Switches	Honeywell	14
1LS2-4PG	Industrial Limit Switches	Honeywell	6
1LS244-4PG	Industrial Limit Switches	Honeywell	9
1LS3-4PG	Industrial Limit Switches	Honeywell	7
1LS47-4PG	Industrial Limit Switches	Honeywell	2
1PA4	Industrial Limit Switches	Honeywell	10
1TB1-1	Large Basics	Honeywell	1
1TB1-3	Large Basics	Honeywell	6
1XE301	Aero Sealed Switch Legacy	Honeywell	1
201LS2-4	Industrial Limit Switches	Honeywell	1
20PCWHRC	20PC option part	Honeywell	16
2455R-00820688	Commercial Thermal	Honeywell	1
24PCFFA6G	PCB pressure sensor	Honeywell	3
26PCCFA1G	PCB pressure sensor	Honeywell	1
26PCCFA6G	PCB pressure sensor	Honeywell	1
2MN1M/1PA22-4	Industrial Limit Switches	Honeywell	20
2MN8M/1PA39-4	Industrial Limit Switches	Honeywell	15

2SX1-T	Subminiature Basics	Honeywell	7
2TL1-1	Toggles & Rockers	Honeywell	1
2TL49-5K	Toggles & Rockers	Honeywell	1
2TL5-7	Toggles & Rockers	Honeywell	2
2TM-15T-7	Switch	Honeywell	57
311SM2-T	Subminiature Basics	Honeywell	318
311SM3-T	Subminiature Basics	Honeywell	4
311SM6-T	Subminiature Basics	Honeywell	3
311SM7-T	Subminiature Basics	Honeywell	18
311SX2-T	Subminiature Basics	Honeywell	1
313SX3-T	Subminiature Basics	Honeywell	1
3PA2	Industrial Limit Switches	Honeywell	3
411SM1	Subminiature Basics	Honeywell	3
4TL1-2	Toggles & Rockers	Honeywell	5
4TL1-8	Toggles & Rockers	Honeywell	1
511TS1-1	Toggles & Rockers	Honeywell	33
511TS1-2	Toggles & Rockers	Honeywell	1
5LS1-4PG	Industrial Limit Switches	Honeywell	3
5SE1	Subminiature Basics	Honeywell	7
5XE1-6	Aero Sealed Switch Legacy	Honeywell	1
5SE1-6N26	Aero Sealed Switch Legacy	Honeywell	12
6655-90980004	Thermistors	Honeywell	38
6655-91000001	Thermistors	Honeywell	48
6HM1-3	Aero Sealed Switch Legacy	Honeywell	2
6PA67-4	Industrial Limit Switches	Honeywell	10
6PA78-4	Industrial Limit Switches	Honeywell	18
8A-2011	Subminiature Basics	Honeywell	25
8C-1011	Subminiature Basics	Honeywell	91
8C-1012	Subminiature Basics	Honeywell	743
8P-1021-007	Industrial Limit Switches	Honeywell	3
8P-1021-B	Industrial Limit Switches	Honeywell	4
8P-2011-007	Industrial Limit Switches	Honeywell	100
8Z-0081	Switch	Honeywell	120
8Z-0082	Switch	Honeywell	250
8Z-0083	Switch	Honeywell	176
8Z0152	Switch	Honeywell	476
904-VB1-PG	Switch	Honeywell	45
908AS-2RQ8	Switch	Honeywell	7
918PA1-PG	Switch	Honeywell	1
935PA1	Industrial Limit Switches	Honeywell	10
9PA16-4	Industrial Limit Switches	Honeywell	4
9PA33-4	Industrial Limit Switches	Honeywell	4
AML-22CBJ3AD	Push Buttons	Honeywell	20
AML-31FBA4AC01	Push Buttons	Honeywell	8
AML-35FBC7AC01	Push Buttons	Honeywell	146
AML-36FBC4AC01	Push Buttons	Honeywell	147
AML-52C10Y	Push Buttons	Honeywell	30
AML-54F10K	Push Buttons	Honeywell	17
AML-55N10TK	Push Buttons	Honeywell	199
AML-56N10RK	Push Buttons	Honeywell	275
AML-56N10TK	Push Buttons	Honeywell	121
AT-10063W	Subminiature Basics	Honeywell	100
AWM2100V	Air Flow Sensor	Honeywell	1
AWM3100V	Air Flow Sensor	Honeywell	1
AWM43300V	Air Flow Sensor	Honeywell	43
AWM5102VN	Air Flow Sensor	Honeywell	4
AWM5104VC	Air Flow Sensor	Honeywell	2
BA-2RV22-A2	Large Basic Switch	Honeywell	2
BAF3-2RN18-LHPG	Large Basic Switch	Honeywell	7
BZ-22RM-A2	Large Basic Switch	Honeywell	10
BZ-2G-A2	Large Basic Switch	Honeywell	1
BZ-2R	Large Basic Switch	Honeywell	2
BZ-2R-A2	Large Basic Switch	Honeywell	4

BZ-2R55-A2	Large Basic Switch	Honeywell	1
BZ-2RD	Large Basic Switch	Honeywell	10
BZ-2RL	Large Basic Switch	Honeywell	1
BZ-2RL-2	Large Basic Switch	Honeywell	1
BZ-2RM-A2	Large Basic Switch	Honeywell	2
BZ-2RQ-18-J	Large Basic Switch	Honeywell	190
BZ-2RQ1-T04	Large Basic Switch	Honeywell	1
BZ-2RQ18M	Large Basic Switch	Honeywell	1
BZ-2RS	Large Basic Switch	Honeywell	31
BZ-2RW-80	Large Basic Switch	Honeywell	66
BZ-2RW-82	Large Basic Switch	Honeywell	34
BZ-2RW-825	Large Basic Switch	Honeywell	31
BZ-2RW-826	Large Basic Switch	Honeywell	171
BZ-2RW-826-A2	Large Basic Switch	Honeywell	2
BZ-2RW-84	Large Basic Switch	Honeywell	93
BZ-2RW82-A2	Large Basic Switch	Honeywell	1
BZ-2RW825-A2	Large Basic Switch	Honeywell	119
BZ-2RW826	Large Basic Switch	Honeywell	9
BZ-2RW8299-A2	Large Basic Switch	Honeywell	1
BZ-2RW855-A2	Large Basic Switch	Honeywell	20
BZ-R-A2	Large Basic Switch	Honeywell	2
BZ-R19	Large Basic Switch	Honeywell	1
BZE7-2RQ8-PG	Large Basic Switch	Honeywell	21
BZE7-2RQ81-PG	Large Basic Switch	Honeywell	16
BZE7-2RQ9-PG	Large Basic Switch	Honeywell	2
CLSA1CH	Current Sensor	Honeywell	2
CSDA1BC	Current Sensor	Honeywell	2
CSLE4AD	Current Sensor	Honeywell	2
CSNH151	Current Sensor	Honeywell	10
CSNP661	Current Sensor	Honeywell	2
DT-2RV-22-A7	Large Basic Switch	Honeywell	49
DTF2-2RN-RH	Large Basic Switch	Honeywell	4
HAFBSF0200C2AX5	Air Flow Sensor	Honeywell	1
HC4-DC48V	Relay	Honeywell	299
HEL-705-T-0-12-00	Humidity Sensort	Honeywell	1
HIH-4031-001	Humidity Sensort	Honeywell	70
HMC1021Z	Mangentoresistive Sensor	Honeywell	1
HMC1051Z	Mangentoresistive Sensor	Honeywell	22
HMC1052	Mangentoresistive Sensor	Honeywell	1
HOA1404-002	Infrared Sensor	Honeywell	1
JE-1	Lever for switches	Honeywell	18
JE-5	Lever for switches	Honeywell	55
JS-2	Lever for switches	Honeywell	235
JS-2-C	Lever for switches	Honeywell	8
JS-220	Lever for switches	Honeywell	10
JS-246-C	Lever for switches	Honeywell	71
JS-31	Lever for switches	Honeywell	2
JS-33	Lever for switches	Honeywell	3
JS-5J	Lever for switches	Honeywell	3
JS-7	Lever for switches	Honeywell	58
JV-9020-C	Lever for switches	Honeywell	25
JX-20	Lever for switches	Honeywell	10
JX-206	Lever for switches	Honeywell	4
JX-4	Lever for switches	Honeywell	3
JX-47	Lever for switches	Honeywell	211
JX-95	Lever for switches	Honeywell	2
LML-2-S	Foot Switch	Honeywell	10
M922AA1Y-B4P-L	switch	Honeywell	1
M5594/1-2	Toggles & Rockers	Honeywell	5
M5594/1-3	Toggles & Rockers	Honeywell	22
MT-4RL2	Large Basic Switch	Honeywell	5
PC-10182	20PC option part	Honeywell	65
PC-10198	20PC option part	Honeywell	27

SS-12125	Hall Sensor	Honeywell	1
SS41	Hall Sensor	Honeywell	2
SS496A1	Hall Sensor	Honeywell	21
SS496A1-S	Hall Sensor	Honeywell	4
SS496A1-SP	Hall Sensor	Honeywell	4
SS94A1F	Hall Sensor	Honeywell	2
SSCDANN100MGAA3	PCB Pressure Sensor	Honeywell	2
SSCDANN100MGAA5	PCB Pressure Sensor	Honeywell	2
SSCSRNN400MGAA5	PCB Pressure Sensor	Honeywell	2
SSCSRNN400MGAA5	PCB Pressure Sensor	Honeywell	2
TD5A	Ptemperature Sensor	Honeywell	1
V3 9101M 11K	Micro Switch	Honeywell	1
V3 9101M-D18	Micro Switch	Honeywell	1
V3 9101M11-D18	Micro Switch	Honeywell	1
V3 9132M20	Micro Switch	Honeywell	1
V3 9245M	Micro Switch	Honeywell	2
V3 99128 M9 D18	Micro Switch	Honeywell	1
V3 99245M D18	Micro Switch	Honeywell	1
V3-101-D9	Micro Switch	Honeywell	1
V3-1101-D8	Micro Switch	Honeywell	39
V3-5000-S	Micro Switch	Honeywell	1
V3-5100	Micro Switch	Honeywell	1
V3-9001M-D18	Micro Switch	Honeywell	2
V3-9001M-F	Micro Switch	Honeywell	2
V3-9019M	Micro Switch	Honeywell	167
V3-9023M	Micro Switch	Honeywell	6
V3-9043	Micro Switch	Honeywell	1
V3-9101M-F	Micro Switch	Honeywell	9
V3-9115M	Micro Switch	Honeywell	613
V3-9115M11	Micro Switch	Honeywell	14
V309101M 11K	Micro Switch	Honeywell	1
V399246M	Micro Switch	Honeywell	4
V3L09101M11K	Micro Switch	Honeywell	1
V3L1122-D8	Micro Switch	Honeywell	3
V3LB9101M	Micro Switch	Honeywell	5
V3LD9101M20D18	Micro Switch	Honeywell	1
V3LE99123	Micro Switch	Honeywell	1
V4-14	Micro Switch	Honeywell	2
V5C010BB	Micro Switch	Honeywell	3
V5C010BB1D	Micro Switch	Honeywell	35
V7-3S17D8-048	Micro Switch	Honeywell	2
V91031CB	Micro Switch	Honeywell	6
V92031BB	Micro Switch	Honeywell	10
VR5C010BB3	Micro Switch	Honeywell	1
XN300736V3	XN300736V3	Honeywell	7
ZM50E70A01	XN300736V3	Honeywell	10
1HT1	High Temperature Switch	Honeywell	16
3HT1	High Temperature Switch	Honeywell	75
GMS10RVS	Oxygen Sensor	Honeywell	10
CH291-1220LF/T&R	Batteryholder / Batterycontact	Comfortable	4000
CH74-2032LF	Batteryholder / Batterycontact	Comfortable	7460
B318D	Batteryholder / Batterycontact	Comfortable	20000
B404B	Batteryholder / Batterycontact	Comfortable	500
BH131D	Batteryholder / Batterycontact	Comfortable	2400
BH432	Batteryholder / Batterycontact	Comfortable	30022
BS-IR-150	Batteryholder / Batterycontact	Comfortable	21500
BS-TR-150	Batteryholder / Batterycontact	Comfortable	4100
19C200PA1K	Pressure Sensor	Honeywell	3
10PA4	Large Basic Switch	Honeywell	1
111SM2-T	Subminiature Basics	Honeywell	50
11TW1-1L	Toggles & Rockers	Honeywell	61
11TW1-3	Toggles & Rockers	Honeywell	1
11TW1-3F	Toggles & Rockers	Honeywell	32

11TW1-8	Toggles & Rockers	Honeywell	9
12TW1-1	Toggles & Rockers	Honeywell	10
12TW1-10A	Toggles & Rockers	Honeywell	85
12TW1-1A	Toggles & Rockers	Honeywell	80
12TW1-3	Toggles & Rockers	Honeywell	65
12TW1-3F	Toggles & Rockers	Honeywell	22
12TW1-7	Toggles & Rockers	Honeywell	172
12TW1-8	Toggles & Rockers	Honeywell	10
14CE18-6AH	Toggles & Rockers	Honeywell	8
14CE2-3K	Toggles & Rockers	Honeywell	15
14CE3-3K	Industrial Limit Switches	Honeywell	14
163-PC-01D75	Pressure Sensor	Honeywell	10
18PA1-4PG	Industrial Limit Switches	Honeywell	35
1HT1	High Temperature Switch	Honeywell	139
1LS1-4C	Industrial Limit Switches	Honeywell	1
1LS1-4PG	Industrial Limit Switches	Honeywell	3
1LS243-4PG	Industrial Limit Switches	Honeywell	2
1LS244-4PG	Industrial Limit Switches	Honeywell	25
1NT1-2	Toggles & Rockers	Honeywell	149
1NT1-3	Toggles & Rockers	Honeywell	35
1NT1-4	Toggles & Rockers	Honeywell	73
1NT1-6	Toggles & Rockers	Honeywell	51
1NT1-7	Toggles & Rockers	Honeywell	156
1SX1-T	Toggles & Rockers	Honeywell	520
1TB1-1	Toggles & Rockers	Honeywell	15
1XE1-3	Subminiature Basics	Honeywell	62
201LS2-4	Industrial Limit Switches	Honeywell	10
201LS3-4	Industrial Limit Switches	Honeywell	1
208LS1-4	Industrial Limit Switches	Honeywell	12
23SX39-T	Subminiature Basics	Honeywell	75
2455RM-90820468	Thermostate	Honeywell	100
25ET61-S	Aero Sealed Switch Legacy	Honeywell	44
26PC01SMT	pressure sensor	Honeywell	5
26PC05SMT	Pressure Sensor	Honeywell	989
26PC15SMT	Pressure Sensor	Honeywell	820
26PCAF2G	Pressure Sensor	Honeywell	75
26PCBFA6D	PCB pressure sensor	Honeywell	115
26PCBFA6G	PCB pressure sensor	Honeywell	7
26PCBFM6G	PCB pressure sensor	Honeywell	68
26PCCFA6D	PCB pressure sensor	Honeywell	3
26PCCFA6G	PCB pressure sensor	Honeywell	150
26PCCFH6G	PCB pressure sensor	Honeywell	10
2LS1-4PG	Industrial Limit Switches	Honeywell	24
2NT1-10	Toggles & Rockers	Honeywell	330
2NT1-3	Toggles & Rockers	Honeywell	58
2NT1-5N	Toggles & Rockers	Honeywell	25
2NT1-7	Toggles & Rockers	Honeywell	150
2SS52M	Toggles & Rockers	Honeywell	701
311SM68-T	Subminiature Basics	Honeywell	425
4AV19F	Hallsensor	Honeywell	100
5PA2	Industrial Limit Switches	Honeywell	2
6HM1-1	Aero Sealed Switch Legacy	Honeywell	78
6PA56-4	Industrial Limit Switches	Honeywell	2
8LS1-4C	Industrial Limit Switches	Honeywell	15
8LS1-4PG	Industrial Limit Switches	Honeywell	6
91SS12-2	Hallsensor	Honeywell	172
9PA58-4	Industrial Limit Switches	Honeywell	20
ABPDANN005PG2A3	Basic Pressure Sensor	Honeywell	50
ABPDANT005PGA5	Basic Pressure Sensor	Honeywell	40
ABPDANT015PGA5	Basic Pressure Sensor	Honeywell	30
ABPDANT060PGA5	Basic Pressure Sensor	Honeywell	40
ABPDJTT001PGA5	Basic Pressure Sensor	Honeywell	5
ABPDLNN100MG2A3	Basic Pressure Sensor	Honeywell	15

ABPDRRT005PG2A5	Basic Pressure Sensor	Honeywell	43
ABPLLND060MGAA3	Basic Pressure Sensor	Honeywell	50
ABPLLNN015PG2D3	Basic Pressure Sensor	Honeywell	46
ABPLLNN600MGAA3	Basic Pressure Sensor	Honeywell	15
ABPLLNT010BGAA5	Basic Pressure Sensor	Honeywell	23
ABPMAND001PG2A3	Basic Pressure Sensor	Honeywell	10
ABPMANN004BGAA5	Basic Pressure Sensor	Honeywell	20
ABPMANN005PGAA3	Basic Pressure Sensor	Honeywell	50
ABPMANN030PG2A3	Basic Pressure Sensor	Honeywell	45
ABPMJTT015PGAA5	Basic Pressure Sensor	Honeywell	10
ABPMLNN001PGAA3	Basic Pressure Sensor	Honeywell	15
AWM2100V	Air Flow Sensor	Honeywell	70
AWM2300V	Air Flow Sensor	Honeywell	300
AWM3100V	Air Flow Sensor	Honeywell	122
AWM3303V	Air Flow Sensor	Honeywell	88
AWM42150VH	Air Flow Sensor	Honeywell	69
AWM43300V	Air Flow Sensor	Honeywell	344
AWM5101VN	Air Flow Sensor	Honeywell	73
AWM5102VN	Air Flow Sensor	Honeywell	245
AWM5103VN	Air Flow Sensor	Honeywell	9
AWM5104VC	Air Flow Sensor	Honeywell	910
AWM5104VN	Air Flow Sensor	Honeywell	41
AWM720P1	Air Flow Sensor	Honeywell	98
BZ-2AW822T	Large Basic Switch	Honeywell	617
BZ-2RD-A2	Large Basic Switch	Honeywell	327
BZ-2RQ1-A2	Large Basic Switch	Honeywell	2055
BZ-2RQ13-A2	Large Basic Switch	Honeywell	600
BZ-2RQ18-A2	Large Basic Switch	Honeywell	744
BZ-2RW80-A2	Large Basic Switch	Honeywell	340
BZ-2RW82-A2	Large Basic Switch	Honeywell	487
BZ-2RW822-A2	Large Basic Switch	Honeywell	427
BZ-5RW822-A2-F2	Large Basic Switch	Honeywell	2993
BZ-E7-2RN-C	Large Basic Switch	Honeywell	33
BZ-E7-2RN2-C	Large Basic Switch	Honeywell	2
BZ-R21	Large Basic Switch	Honeywell	232
BZ-R7216	Large Basic Switch	Honeywell	1
BZE7-2RN-PG	Large Basic Switch	Honeywell	14
CPC30AFH	Current Sensor	Honeywell	300
CSDA1BC	Current Sensor	Honeywell	37
CSLA1CD	Current Sensor	Honeywell	98
CSLA1CH	Current Sensor	Honeywell	34
CSNS300M	Current Sensor	Honeywell	5
CSNX25	Pressure sensor	Honeywell	35
DCXL10DS	Pressure sensor	Honeywell	45
FRN22212	pressure switch	Honeywell	305
FSG15N1A	force sensor	Honeywell	21
FSS015WNGB	force sensor	Honeywell	147
FSS1500NSB	force sensor	Honeywell	150
GLAC01A1B	Industrial Limit Switches	Honeywell	6
GLAC01C	Industrial Limit Switches	Honeywell	26
GLAC07A2B	Industrial Limit Switches	Honeywell	15
GLAC20C	Industrial Limit Switches	Honeywell	31
GLCC01A1A	Industrial Limit Switches	Honeywell	16
GLCC01A1B	Industrial Limit Switches	Honeywell	51
GLCC01A2B	Industrial Limit Switches	Honeywell	32
GLDC01A1A	Industrial Limit Switches	Honeywell	50
GTN1A131	speed sensor	Honeywell	128
HAFBSF0200C4AX3	Air Flow Sensor	Honeywell	290
HAFBSS0200C4AX3	Air Flow Sensor	Honeywell	1
HEL-705-T-0-12-00	Temperature Sensor	Honeywell	56
HEL-705-U-0-12-00	Temperature Sensor	Honeywell	200
HEL-707-U-0-12-00	Temperature Sensor	Honeywell	25
HIH-4000-001	Humidity Sensor	Honeywell	75



HIH-4000-002	Humidity Sensor	Honeywell	1575
HIH-4010-001	Humidity Sensor	Honeywell	30
HIH-4010-002	Humidity Sensor	Honeywell	110
HIH-4010-004	Humidity Sensor	Honeywell	20
HIH-4020-001	Humidity Sensor	Honeywell	39
HIH-4020-002	Humidity Sensor	Honeywell	1
HIH-4020-004	Humidity Sensor	Honeywell	22
HIH-4021-001	Humidity Sensor	Honeywell	39
HIH-4021-002	Humidity Sensor	Honeywell	29
HIH-4021-004	Humidity Sensor	Honeywell	26
HIH-4030-001	Humidity Sensor	Honeywell	30
HIH-4602-L	Humidity Sensor	Honeywell	28
HIH-4602-L-CP	Humidity Sensor	Honeywell	5160
HIH-5031-001	Humidity Sensor	Honeywell	815
HIH-6131-021-001	Humidity Sensor	Honeywell	34
HIH-7130-021-001	Humidity Sensor	Honeywell	50
HIH-7131-021-001	Humidity Sensor	Honeywell	21
HIH-8130-021-001	Humidity Sensor	Honeywell	7
HIH-8131-021-001	Humidity Sensor	Honeywell	7
HIH-9130-021-001	Humidity Sensor	Honeywell	55
HLC-131-020	option part for LLN sensor	Honeywell	2
HMC1021S	Magnet Sensor	Honeywell	10
HMC1021ZRC	Magnet Sensor	Honeywell	4
HMC1022	Magnet Sensor	Honeywell	147
HMC1051ZRC	Magnet Sensor	Honeywell	3
HOA0901-012	Infrared Sensor	Honeywell	200
HOA1879-011	Infrared Sensor	Honeywell	46
HSCMANN1.6BA3A3	Pressure sensor	Honeywell	30
JE-61	Lever for switches	Honeywell	250
JS-151	Lever for switches	Honeywell	12
JS-5	Lever for switches	Honeywell	39
JV-5	Lever for switches	Honeywell	200
JV-9005-C	Lever for switches	Honeywell	5
JV-9007-C	Lever for switches	Honeywell	1
JX-41	Lever for switches	Honeywell	141
JX-42	Lever for switches	Honeywell	50
JX-51	Lever for switches	Honeywell	100
LLE101000	Lequid level sensor	Honeywell	21
LLE101101	Lequid level sensor	Honeywell	4
LLE102101	Lequid level sensor	Honeywell	60
LLE103101	Lequid level sensor	Honeywell	14
LLE105100	Lequid level sensor	Honeywell	10
LLE205100	Lequid level sensor	Honeywell	50
LLN865172-1	Lequid level sensor	Honeywell	22
LLN865172-2	Lequid level sensor	Honeywell	9
LM972-S	Foot Switch	Honeywell	34
LSYK1ADD-8C-C	Industrial Limit Switches	Honeywell	27
LSZ3A	Industrial Limit Switches	Honeywell	5
MLT002N3000B5C/KONF	Linear position sensor	Honeywell	1
NGCMA50AX32A1A	Industrial Limit Switches	Honeywell	13
NGCMB10AX01C	Industrial Limit Switches	Honeywell	1
NGCMC10AX01A1A	Industrial Limit Switches	Honeywell	4
NGCPA10AX01A1A	Industrial Limit Switches	Honeywell	4
NGCPA10AX01B	Industrial Limit Switches	Honeywell	4
NGCPA10AX01C	Industrial Limit Switches	Honeywell	4
NGCPA10AX01L	Industrial Limit Switches	Honeywell	2
NGCPA50AX32A1A	Industrial Limit Switches	Honeywell	9
NGCPA50AX32B	Industrial Limit Switches	Honeywell	8
NGCPA50AX32C	Industrial Limit Switches	Honeywell	9
NGCPA50AX32L	Industrial Limit Switches	Honeywell	9
NGCPB10AX01B	Industrial Limit Switches	Honeywell	1
NGCPB10AX01L	Industrial Limit Switches	Honeywell	1
PC-10182	option part for pressure sensor	Honeywell	10

RTY090HVEAX	Angle sensor	Honeywell	6
RTY180HVEAX	Angle sensor	Honeywell	39
RTY270HVEAX	Angle sensor	Honeywell	50
RTY360HVEAX	Angle sensor	Honeywell	30
SCX01DNC	Pressure sensor	Honeywell	44
SCX05DNC	Pressure sensor	Honeywell	319
SCX30ANC	Pressure sensor	Honeywell	101
SCXL004DN	Pressure sensor	Honeywell	1
SD1440-004L	Infrared Sensor	Honeywell	3443
SDP8405-003	Infrared Sensor	Honeywell	250
SDP8600-001	Infrared Sensor	Honeywell	645
SDX010IND4	Pressure sensor	Honeywell	75
SDX100A2	Pressure sensor	Honeywell	35
SDX30A4	Pressure sensor	Honeywell	23
SDX30D4	Pressure sensor	Honeywell	400
SE1470-003L	Infrared Sensor	Honeywell	4000
SE1470-004L	Infrared Sensor	Honeywell	2634
SEK001	demo board	Honeywell	9
SEK002	demo board	Honeywell	9
SEP8506-003	Infrared Sensor	Honeywell	200
SEP8706-003	Infrared Sensor	Honeywell	1067
SL353HT	Hallsensor	Honeywell	2750
SM351LT	Hallsensor	Honeywell	2750
SPS-L225-HALS	Linear position sensor	Honeywell	7
SPS-L225-HDLS	Linear position sensor	Honeywell	8
SPS-R360D_5PIN_PLUG	Linear position sensor	Honeywell	12
SR17C-J6	Hallsensor	Honeywell	305
SS-461A	Hallsensor	Honeywell	3886
SS41	Hallsensor	Honeywell	3205
SS411A	Hallsensor	Honeywell	774
SS413A	Hallsensor	Honeywell	22150
SS441A	Hallsensor	Honeywell	1248
SS443A	Hallsensor	Honeywell	791
SS466A	Hallsensor	Honeywell	197
SS495A	Hallsensor	Honeywell	250
SS495A-SP	Hallsensor	Honeywell	750
SS495A1	Hallsensor	Honeywell	1790
SS543AT	Hallsensor	Honeywell	558
SS549AT	Hallsensor	Honeywell	775
SS59ET	Hallsensor	Honeywell	746
SS94A1	Hallsensor	Honeywell	336
SS94A1F	Hallsensor	Honeywell	39
SS94A2	Hallsensor	Honeywell	110
SSCDRRN004NDAAS	pressure sensor	Honeywell	6
SSCSAAN004ND2AS	Pressure sensor	Honeywell	225
TBPLLNN015PGUCV	pressure sensor	Honeywell	400
TD4A	Temperature Sensor	Honeywell	26
V15W11-WZ200A02-W2	Micro Switch	Honeywell	750
V15W11-WZ200A04-W2	Micro Switch	Honeywell	103
V15W11-WZ200A04-W3	Micro Switch	Honeywell	295
XPC01GTH	Pressure sensor	Honeywell	30
101	Batteryholder / Batterycontact	Honeywell	125
1012	Batteryholder / Batterycontact	Honeywell	124
1018	Batteryholder / Batterycontact	Honeywell	778
1022KEY	Batteryholder / Batterycontact	Honeywell	20
1023	Batteryholder / Batterycontact	Honeywell	75
1024	Batteryholder / Batterycontact	Keystone	228
1025	Batteryholder / Batterycontact	Keystone	445
1027	Batteryholder / Batterycontact	Keystone	93
1028	Batteryholder / Batterycontact	Keystone	5750
1028 C	Batteryholder / Batterycontact	Keystone	7753
1029	Batteryholder / Batterycontact	Keystone	2716
1029 C	Batteryholder / Batterycontact	Keystone	1040

1029LC	Batteryholder / Batterycontact	Keystone	4950
103	Batteryholder / Batterycontact	Keystone	9495
1033	Batteryholder / Batterycontact	Keystone	95
1042	Batteryholder / Batterycontact	Keystone	171
1042P	Batteryholder / Batterycontact	Keystone	62
1043	Batteryholder / Batterycontact	Keystone	175
1043P	Batteryholder / Batterycontact	Keystone	20
1044	Batteryholder / Batterycontact	Keystone	100
1047	Batteryholder / Batterycontact	Keystone	260
1048	Batteryholder / Batterycontact	Keystone	220
1049	Batteryholder / Batterycontact	Keystone	23
105	Batteryholder / Batterycontact	Keystone	1317
1053	Batteryholder / Batterycontact	Keystone	20
1056TR	Batteryholder / Batterycontact	Keystone	3
1058	Batteryholder / Batterycontact	Keystone	50
1059	Batteryholder / Batterycontact	Keystone	1160
106	Batteryholder / Batterycontact	Keystone	10537
1060	Batteryholder / Batterycontact	Keystone	98
1061	Batteryholder / Batterycontact	Keystone	371
1065	Batteryholder / Batterycontact	Keystone	534
1066	Batteryholder / Batterycontact	Keystone	4381
1067	Batteryholder / Batterycontact	Keystone	511
1068	Batteryholder / Batterycontact	Keystone	690
1069	Batteryholder / Batterycontact	Keystone	74
107	Batteryholder / Batterycontact	Keystone	493
1070	Batteryholder / Batterycontact	Keystone	733
108	Batteryholder / Batterycontact	Keystone	855
108-2	Batteryholder / Batterycontact	Keystone	52371
108-C	Batteryholder / Batterycontact	Keystone	3678
1081	Batteryholder / Batterycontact	Keystone	18
1089	Batteryholder / Batterycontact	Keystone	2
109-3	Batteryholder / Batterycontact	Keystone	2
1090	Batteryholder / Batterycontact	Keystone	2
1095P	Batteryholder / Batterycontact	Keystone	75
1096P	Batteryholder / Batterycontact	Keystone	115
1097	Batteryholder / Batterycontact	Keystone	50
1097P	Batteryholder / Batterycontact	Keystone	25
1098	Batteryholder / Batterycontact	Keystone	80
1098P	Batteryholder / Batterycontact	Keystone	20
1101	Batteryholder / Batterycontact	Keystone	80
1102	Batteryholder / Batterycontact	Keystone	25
1107	Batteryholder / Batterycontact	Keystone	141
1108	Batteryholder / Batterycontact	Keystone	83
1109	Batteryholder / Batterycontact	Keystone	100
1114	Batteryholder / Batterycontact	Keystone	2
112	Batteryholder / Batterycontact	Keystone	2622
117-LABEL	Batteryholder / Batterycontact	Keystone	514
120	Batteryholder / Batterycontact	Keystone	80
122TR	Batteryholder / Batterycontact	Keystone	2000
1294	Batteryholder / Batterycontact	Keystone	600
1295	Batteryholder / Batterycontact	Keystone	1100
138	Batteryholder / Batterycontact	Keystone	101
146	Batteryholder / Batterycontact	Keystone	80
147	Batteryholder / Batterycontact	Keystone	60
148	Batteryholder / Batterycontact	Keystone	70
149	Batteryholder / Batterycontact	Keystone	60
151	Batteryholder / Batterycontact	Keystone	76
152	Batteryholder / Batterycontact	Keystone	28
158	Batteryholder / Batterycontact	Keystone	50
175	Batteryholder / Batterycontact	Keystone	4
202	Batteryholder / Batterycontact	Keystone	4736
204	Batteryholder / Batterycontact	Keystone	12344
209	Batteryholder / Batterycontact	Keystone	8309

210	Batteryholder / Batterycontact	Keystone	5000
211	Batteryholder / Batterycontact	Keystone	43
211 D	Batteryholder / Batterycontact	Keystone	950
2239	Batteryholder / Batterycontact	Keystone	100
2242	Batteryholder / Batterycontact	Keystone	100
228	Batteryholder / Batterycontact	Keystone	2600
230-1	Batteryholder / Batterycontact	Keystone	50
238	Batteryholder / Batterycontact	Keystone	1527
2413	Batteryholder / Batterycontact	Keystone	20
2460RB	Batteryholder / Batterycontact	Keystone	500
2468	Batteryholder / Batterycontact	Keystone	153
261	Batteryholder / Batterycontact	Keystone	131
269	Batteryholder / Batterycontact	Keystone	16
288	Batteryholder / Batterycontact	Keystone	95
290	Batteryholder / Batterycontact	Keystone	1391
291	Batteryholder / Batterycontact	Keystone	794
2915	Batteryholder / Batterycontact	Keystone	3
295	Batteryholder / Batterycontact	Keystone	2944
296	Batteryholder / Batterycontact	Keystone	1615
2982	Batteryholder / Batterycontact	Keystone	82
2988	Batteryholder / Batterycontact	Keystone	2
2990	Batteryholder / Batterycontact	Keystone	920
2991	Batteryholder / Batterycontact	Keystone	6810
2991TR	Batteryholder / Batterycontact	Keystone	1500
2992TR	Batteryholder / Batterycontact	Keystone	395
2996	Batteryholder / Batterycontact	Keystone	1968
2998	Batteryholder / Batterycontact	Keystone	557
2999	Batteryholder / Batterycontact	Keystone	517
3000	Batteryholder / Batterycontact	Keystone	1076
3001	Batteryholder / Batterycontact	Keystone	72
3002	Batteryholder / Batterycontact	Keystone	253
3002TR	Batteryholder / Batterycontact	Keystone	3500
3003	Batteryholder / Batterycontact	Keystone	10382
3005	Batteryholder / Batterycontact	Keystone	1400
3006TR	Batteryholder / Batterycontact	Keystone	1200
3008	Batteryholder / Batterycontact	Keystone	803
3008TR	Batteryholder / Batterycontact	Keystone	23000
3009	Batteryholder / Batterycontact	Keystone	188
3012	Batteryholder / Batterycontact	Keystone	509
3013	Batteryholder / Batterycontact	Keystone	3
3020	Batteryholder / Batterycontact	Keystone	208
3022	Batteryholder / Batterycontact	Keystone	100
3026	Batteryholder / Batterycontact	Keystone	102
3027	Batteryholder / Batterycontact	Keystone	1032
3517	Batteryholder / Batterycontact	Keystone	844
4814	Batteryholder / Batterycontact	Keystone	6000
500	Batteryholder / Batterycontact	Keystone	9902
5001	Batteryholder / Batterycontact	Keystone	1336
5004	Batteryholder / Batterycontact	Keystone	2
5006	Batteryholder / Batterycontact	Keystone	1590
5011	Batteryholder / Batterycontact	Keystone	500
5017	Batteryholder / Batterycontact	Keystone	25
502	Batteryholder / Batterycontact	Keystone	5061
502-3	Batteryholder / Batterycontact	Keystone	250
5201	Batteryholder / Batterycontact	Keystone	23944
5202	Batteryholder / Batterycontact	Keystone	14245
5203	Batteryholder / Batterycontact	Keystone	2530
5204	Batteryholder / Batterycontact	Keystone	1434
5208	Batteryholder / Batterycontact	Keystone	5000
5209	Batteryholder / Batterycontact	Keystone	10
5212	Batteryholder / Batterycontact	Keystone	9000
5213	Batteryholder / Batterycontact	Keystone	217
5214	Batteryholder / Batterycontact	Keystone	1740

5218	Batteryholder / Batterycontact	Keystone	5
5221	Batteryholder / Batterycontact	Keystone	665
5223	Batteryholder / Batterycontact	Keystone	39
5224	Batteryholder / Batterycontact	Keystone	8264
5225	Batteryholder / Batterycontact	Keystone	6064
5226	Batteryholder / Batterycontact	Keystone	4055
5230	Batteryholder / Batterycontact	Keystone	1600
5231	Batteryholder / Batterycontact	Keystone	1935
5231TR	Batteryholder / Batterycontact	Keystone	4000
54/18650	Batteryholder / Batterycontact	Keystone	800
56TR	Batteryholder / Batterycontact	Keystone	2500
57	Batteryholder / Batterycontact	Keystone	6177
590	Batteryholder / Batterycontact	Keystone	4318
591	Batteryholder / Batterycontact	Keystone	7882
593	Batteryholder / Batterycontact	Keystone	371
594	Batteryholder / Batterycontact	Keystone	500
595	Batteryholder / Batterycontact	Keystone	3388
628	Batteryholder / Batterycontact	Keystone	3822
629	Batteryholder / Batterycontact	Keystone	4706
635	Batteryholder / Batterycontact	Keystone	3
7143	Batteryholder / Batterycontact	Keystone	90
7170	Batteryholder / Batterycontact	Keystone	42
82	Batteryholder / Batterycontact	Keystone	21038
9-5230-191	Batteryholder / Batterycontact	Keystone	13167
9-590-102	Batteryholder / Batterycontact	Keystone	19950
92	Batteryholder / Batterycontact	Keystone	748
967	Batteryholder / Batterycontact	Keystone	50
968	Batteryholder / Batterycontact	Keystone	1272
C-14862-SOM	Batteryholder / Batterycontact	Keystone	6600
9-595-468	Batteryholder / Batterycontact	Keystone	5000
9-628-468	Batteryholder / Batterycontact	Keystone	5000
1020	Batteryholder / Batterycontact	Keystone	20
2482	Batteryholder / Batterycontact	Keystone	1
2490	Batteryholder / Batterycontact	Keystone	2
BH131D	Batteryholder / Batterycontact	Comfortable	2400
BH432/STICKER	Batteryholder / Batterycontact	Comfortable	28022
BS-IR-150	Batteryholder / Batterycontact	Comfortable	21500
ABG-43	Batteryholder / Batterycontact	MPD	3
BA2032	Batteryholder / Batterycontact	MPD	3099
BA2032SM	Batteryholder / Batterycontact	MPD	757
BA3AAPC-UL94V-0	Batteryholder / Batterycontact	MPD	180
BA4AAPC-UL94V-0	Batteryholder / Batterycontact	MPD	150
BC1/3N-C-SM	Batteryholder / Batterycontact	MPD	800
BC3AAPC	Batteryholder / Batterycontact	MPD	99
BC3AASF	Batteryholder / Batterycontact	MPD	113
BC4AAW	Batteryholder / Batterycontact	MPD	114
BC501SM	Batteryholder / Batterycontact	MPD	3
BH 1/3N-C	Batteryholder / Batterycontact	MPD	11956
BH 2N	Batteryholder / Batterycontact	MPD	4886
BH18650-W	Batteryholder / Batterycontact	MPD	140
BH212DW	Batteryholder / Batterycontact	MPD	60
BH26AASF	Batteryholder / Batterycontact	MPD	220
BH26AAW	Batteryholder / Batterycontact	MPD	800
BH26DW	Batteryholder / Batterycontact	MPD	137
BH28DL	Batteryholder / Batterycontact	MPD	2
BH2AAAW	Batteryholder / Batterycontact	MPD	110
BH2AAW	Batteryholder / Batterycontact	MPD	129
BH2DW	Batteryholder / Batterycontact	MPD	60
BH32T-C	Batteryholder / Batterycontact	MPD	1700
BH3AAW	Batteryholder / Batterycontact	MPD	200
BH48DW	Batteryholder / Batterycontact	MPD	10
BHD-2	Batteryholder / Batterycontact	MPD	6
BLP2032SM-GTR	Batteryholder / Batterycontact	MPD	600

BS5 VERTICAL	Batteryholder / Batterycontact	MPD	4250
LP2032SM-JJ-GTR	Batteryholder / Batterycontact	MPD	6
MBHCW	Batteryholder / Batterycontact	MPD	147
BCC	Batteryholder / Batterycontact	MPD	700
BK885	Batteryholder / Batterycontact	MPD	2632
ABG-43	Batteryholder / Batterycontact	MPD	53
ABG-44	Batteryholder / Batterycontact	MPD	50
BA2AAPC	Batteryholder / Batterycontact	MPD	50
BA3AAW	Batteryholder / Batterycontact	MPD	300
BA4AAW	Batteryholder / Batterycontact	MPD	2692
BA4D-S	Batteryholder / Batterycontact	MPD	100
BC-2003	Batteryholder / Batterycontact	MPD	1000
BC2032-E2	Batteryholder / Batterycontact	MPD	100
BC22AAW	Batteryholder / Batterycontact	MPD	100
BC2AAAL	Batteryholder / Batterycontact	MPD	2900
BC2AAAPC	Batteryholder / Batterycontact	MPD	2654
BC2AAAW	Batteryholder / Batterycontact	MPD	700
BC2AASF	Batteryholder / Batterycontact	MPD	1000
BC2AAW	Batteryholder / Batterycontact	MPD	50
BC34AASF	Batteryholder / Batterycontact	MPD	5
BC3AAAW	Batteryholder / Batterycontact	MPD	98
BC4AAAW	Batteryholder / Batterycontact	MPD	120
BC501SMTR	Batteryholder / Batterycontact	MPD	500
BCAA	Batteryholder / Batterycontact	MPD	1708
BCAAAPC	Batteryholder / Batterycontact	MPD	300
BCAAAW	Batteryholder / Batterycontact	MPD	200
BCAAW	Batteryholder / Batterycontact	MPD	140
BH1000G	Batteryholder / Batterycontact	MPD	200
BH13CW	Batteryholder / Batterycontact	MPD	150
BH14AASF	Batteryholder / Batterycontact	MPD	302
BH16AAL	Batteryholder / Batterycontact	MPD	10
BH16AAW	Batteryholder / Batterycontact	MPD	10
BH210CL	Batteryholder / Batterycontact	MPD	30
BH210CW	Batteryholder / Batterycontact	MPD	110
BH223L	Batteryholder / Batterycontact	MPD	100
BH22CL	Batteryholder / Batterycontact	MPD	201
BH24AASF	Batteryholder / Batterycontact	MPD	306
BH26CW	Batteryholder / Batterycontact	MPD	35
BH28AAAW	Batteryholder / Batterycontact	MPD	200
BH2CL	Batteryholder / Batterycontact	MPD	100
BH2CW	Batteryholder / Batterycontact	MPD	100
BH2NW	Batteryholder / Batterycontact	MPD	150
BH3000	Batteryholder / Batterycontact	MPD	200
BH48CW	Batteryholder / Batterycontact	MPD	80
BH4CW	Batteryholder / Batterycontact	MPD	80
BH4NW	Batteryholder / Batterycontact	MPD	100
BH600	Batteryholder / Batterycontact	MPD	1000
BH600-5.8-G	Batteryholder / Batterycontact	MPD	840
BH908T-C	Batteryholder / Batterycontact	MPD	4600
BH9VW	Batteryholder / Batterycontact	MPD	210
BHAA-POL	Batteryholder / Batterycontact	MPD	200
BHC-2	Batteryholder / Batterycontact	MPD	148
BHC-POL	Batteryholder / Batterycontact	MPD	29
BHDW	Batteryholder / Batterycontact	MPD	100
BHSD-2032-L	Batteryholder / Batterycontact	MPD	20
BHSD1225COVER	Batteryholder / Batterycontact	MPD	26
BHSD1225SM	Batteryholder / Batterycontact	MPD	24
BHX1-1632-SCHUB	Batteryholder / Batterycontact	MPD	1085
BHX1-1632-SM/TRPP	Batteryholder / Batterycontact	MPD	937
BHX1-2032-SM	Batteryholder / Batterycontact	MPD	737
BI-2032	Batteryholder / Batterycontact	MPD	14580
BI-UM-1-2	Batteryholder / Batterycontact	MPD	700
BI-UM-3-4	Batteryholder / Batterycontact	MPD	700

BK-030	Batteryholder / Batterycontact	MPD	110
BK-1264-PC8	Batteryholder / Batterycontact	MPD	75
BK-1280-PC6	Batteryholder / Batterycontact	MPD	40
BK-18650-PC4	Batteryholder / Batterycontact	MPD	240
BK-18650-PC6	Batteryholder / Batterycontact	MPD	210
BK-18650-PC8	Batteryholder / Batterycontact	MPD	423
BK-204	Batteryholder / Batterycontact	MPD	20
BK-209	Batteryholder / Batterycontact	MPD	789
BK-228	Batteryholder / Batterycontact	MPD	720
BK-5058	Batteryholder / Batterycontact	MPD	600
BK-5091	Batteryholder / Batterycontact	MPD	500
BK-6049	Batteryholder / Batterycontact	MPD	113
BK-6089	Batteryholder / Batterycontact	MPD	15
BK-868	Batteryholder / Batterycontact	MPD	48
BK-870	Batteryholder / Batterycontact	MPD	4505
BK-874	Batteryholder / Batterycontact	MPD	1201
BK-875	Batteryholder / Batterycontact	MPD	1234
BK-876	Batteryholder / Batterycontact	MPD	1199
BK-880	Batteryholder / Batterycontact	MPD	3200
BK-883	Batteryholder / Batterycontact	MPD	660
BK-883-TR	Batteryholder / Batterycontact	MPD	900
BK-885	Batteryholder / Batterycontact	MPD	5
BK-885-TR	Batteryholder / Batterycontact	MPD	15200
BK-888	Batteryholder / Batterycontact	MPD	399
BK-912	Batteryholder / Batterycontact	MPD	258
BK-912TR	Batteryholder / Batterycontact	MPD	4200
BK-913	Batteryholder / Batterycontact	MPD	5500
BLP2016SM-GTR	Batteryholder / Batterycontact	MPD	20
BS1225-PC	Batteryholder / Batterycontact	MPD	150
BS2450	Batteryholder / Batterycontact	MPD	1800
BS3	Batteryholder / Batterycontact	MPD	900
BU1-M-402	Batteryholder / Batterycontact	MPD	50
BU2032-1-HD-G	Batteryholder / Batterycontact	MPD	420
BU2032SM	Batteryholder / Batterycontact	MPD	5
BU2032SM-BT-GTR	Batteryholder / Batterycontact	MPD	3200
BU2032SM-G	Batteryholder / Batterycontact	MPD	9200
BU2032SM-HD-G	Batteryholder / Batterycontact	MPD	1200
BU2032SM-JJ	Batteryholder / Batterycontact	MPD	400
BU2032SM-JJ-GTR	Batteryholder / Batterycontact	MPD	9860
BU2450SM-JJ-GTR	Batteryholder / Batterycontact	MPD	4250
BV1632-G	Batteryholder / Batterycontact	MPD	100
BVSD-2032-COVER	Batteryholder / Batterycontact	MPD	20
BVSD-2032-PC	Batteryholder / Batterycontact	MPD	40
CB-AA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AA-PC-POS	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-POS	Batteryholder / Batterycontact	MPD	120
ZA5350	Batteryholder / Batterycontact	MPD	30
ZA5350-B	Batteryholder / Batterycontact	MPD	500





























