

Roßmann Electronic GMBH GERMANY		stocklist:	
www.rossmannweb.de	FON: 0049 8807-94994-0	UPDATE	
info@rossmannweb.de	FAX: 0049 8807-94994-29	05.05.2024	update
Item:	Description:	MFQ.:	stock - items:
TB-31-0.6-1.5	thermoelectric cooler	Kryotherm	504
111-202CAK-B01	NTC	Honeywell-Fenwal	1
112-202EAJ-B01	NTC	Honeywell-Fenwal	1
4E-230B-W	Fan, 230V AC, alu case	BISONIC	200
LM2904F-E2	Operational Amplifiers	ROHM	30000
24 PC GFM 6G	pressure sensor	Honeywell	110
24 PC AFA 6D	pressure sensor	Honeywell	115
24 PC CFA 6G	pressure sensor	Honeywell	65
26 PC BFA 6D	pressure sensor	Honeywell	42
26 PC BFA 6G	pressure sensor	Honeywell	18
26 PC AFA 6G	pressure sensor	Honeywell	21
26 PC CFA 6D	pressure sensor	Honeywell	70
SS 441 A	Hall Sensor	Honeywell	2.000
2SS 52 M+S	Hall Sensor	Honeywell	800
AWM 2100 V	Air Flow Sensor	Honeywell	130
AWM 3100 V	Air Flow Sensor	Honeywell	16
AWM 3300 V	Air Flow Sensor	Honeywell	13
CSNE 151-100	Current Sensor	Honeywell	38
CSNE 151-005	Current Sensor	Honeywell	6
6655-90030004	thermostat	Honeywell	13
6655-99580003	thermostat	Honeywell	6
6655-97100901	thermostat	Honeywell	11
6655-99600003	thermostat	Honeywell	9
6655-98980006	thermostat	Honeywell	7
1SE1-6	Sealed switch	honeywell	1
1SE7-3	Sealed switch	honeywell	2
SE1470-001L	Infrared Sensor	Honeywell	80
AP-CFA004GT6HS-T	Cfast data	Cfast data	2
MLT001N1500D5C	potentiometer	Honeywell	25
F38000201	potentiometer	Honeywell	25
28-55	connector	Amphenol	10
173-103LAD-301	temperatursensor	Fenwal / Honeywell	6
173-223LAF-301	temperatursensor	Fenwal / Honeywell	3
HEL-707-T-0-12-00	temperatursensor	honeywell	2
HEL-717-T-0-18-00	temperatursensor	honeywell	2
HEL-707-TT-1-24-00	temperatursensor	honeywell	1
HEL-712-T-1-12-00	temperatursensor	honeywell	1
31060060028	Thermostat	Honeywell	4
8Z-0156	cap for toggleswitch, color:blue	Honeywell	1000
8Z-0158	cap for toggleswitch, color:yellow	Honeywell	500
26PC15SMT	pressure sensor	Honeywell	8
2455R-09130147	Thermostat	Honeywell	2
SS-12143	Connector	Honeywell	20
JV-82	Lever	Honeywell	3
JE-5	Lever	Honeywell	6
54143	isolation for switches	Honeywell	100
9002182	isolation for switches	Honeywell	100
LSYJC-1A-7N	switch	Honeywell	2
440662	thermostat	Honeywell / Fenwal	4
HEL-717-T-0-18-00	Temperatursensor	Honeywell	2
HEL-707-0-12-00	Temperatursensor	honeywell	2

121-103FAJ-Q01	thermalsensor	honeywell	4
120-202EAJ-Q01	thermalsensor	honeywell	4
AP-CFA004GT6HS-T	4GB	APACER	2
242PC100G	pressure sensor	Honeywell	1
FSL05N2C	forcesensor	honeywell	1
FRN11112	pressure switch	Honeywell	1
450-3394-02-03-00	Hardware	Cambion	500
450-3301-01-03-10	Hardware	Cambion	500
160-1457-01-02-00	Hardware	Cambion	2000
460-2970-03-03-00	Hardware	Cambion	2000
140-2089-02-01-00	Hardware	Cambion	1000
450-3708-01-03-00	Hardware	Cambion	10
460-3308-01-03-00	Hardware	Cambion	1500
450-3320-04-03-00	Hardware	Cambion	8
450-3293-01-03-00	Hardware	Cambion	63
450-3278-01-03-00	Hardware	Cambion	1800
450-3286-01-06-00	Hardware	Cambion	940
450-3394-02-03-00	Hardware	Cambion	500
450-3301-01-03-10	Hardware	Cambion	500
460-2970-03-03-00	Hardware	Cambion	1500
460-3308-01-03-00	Hardware	Cambion	1500
400-1803-01-00-20	Batteryholder	Cambion	125
400-2800-01-00-20	Batteryholder	Cambion	150
400-2801-01-00-20	Batteryholder	Cambion	250
400-2803-01-00-20	Batteryholder	Cambion	100
BX0013/1	batteryholder	bulgin	70
1HS41	Sealed switch	Honeywell	1
1HS1	Sealed switch	Honeywell	1
922AA1Y-B4P-L	proximity switch	Honeywell	1
TD5A-03	Temperatursensor	Honeywell	8
921FS1	proximity switch	Honeywell	1
931FSSG	proximity switch	Honeywell	1
962FSS3,5-C	sensor	Honeywell	2
SME2470-001	Infrared Sensor	honeywell	100
176PC07HD2	pressure sensor	honeywell	15
922FS0.8-A4P-G	proximity switch	Honeywell	10
AD0612US-A71GL	DC-FAN, 12V	ADDA	1500
BHX1-2325-SM	Batteryholder / Batterycontact	MPD	400
UG-568/U	RF Connector	Amphenol	150
1012C	Batteryholder / Batterycontact	Keystone	12
1018	Batteryholder / Batterycontact	Keystone	778
1027	Batteryholder / Batterycontact	Keystone	93
1029 C	Cover for 1029	Keystone	1040
1029LC	Cover for 1029	Keystone	4950
1044	Batteryholder / Batterycontact	Keystone	100
1053	Batteryholder / Batterycontact	Keystone	20
1056TR	Batteryholder / Batterycontact	Keystone	3
1059	Batteryholder / Batterycontact	Keystone	1160
1066	Batteryholder / Batterycontact	Keystone	4384
1081	Batteryholder / Batterycontact	Keystone	18
1089	Batteryholder / Batterycontact	Keystone	2
1090	Batteryholder / Batterycontact	Keystone	2
1096P	Batteryholder / Batterycontact	Keystone	115
1097	Batteryholder / Batterycontact	Keystone	50
1097P	Batteryholder / Batterycontact	Keystone	25
1098	Batteryholder / Batterycontact	Keystone	80
1098P	Batteryholder / Batterycontact	Keystone	20
1102	Batteryholder / Batterycontact	Keystone	50
1114	Batteryholder / Batterycontact	Keystone	2
120	Batteryholder / Batterycontact	Keystone	80
122TR	Batteryholder / Batterycontact	Keystone	2000
138	Batteryholder / Batterycontact	Keystone	101
149	Batteryholder / Batterycontact	Keystone	60

151	Batteryholder / Batterycontact	Keystone	76
230-1	Batteryholder / Batterycontact	Keystone	50
2413	Captive Screw	Keystone	20
2460RB	Batteryholder / Batterycontact	Keystone	500
2468	Batteryholder / Batterycontact	Keystone	153
2482	Batteryholder / Batterycontact	Keystone	1
2490	Batteryholder / Batterycontact	Keystone	2
269	Batteryholder / Batterycontact	Keystone	16
288	Batteryholder / Batterycontact	Keystone	1095
2915	Batteryholder / Batterycontact	Keystone	3
2990	Batteryholder / Batterycontact	Keystone	920
2991	Batteryholder / Batterycontact	Keystone	6810
2996	Batteryholder / Batterycontact	Keystone	1968
2998	Batteryholder / Batterycontact	Keystone	557
3001	Batteryholder / Batterycontact	Keystone	72
3005	Batteryholder / Batterycontact	Keystone	1400
3006TR	Batteryholder / Batterycontact	Keystone	1200
3008	Batteryholder / Batterycontact	Keystone	803
3009	Batteryholder / Batterycontact	Keystone	188
3020	Batteryholder / Batterycontact	Keystone	208
3026	Batteryholder / Batterycontact	Keystone	102
3027	Batteryholder / Batterycontact	Keystone	1032
3096	Batteryholder / Batterycontact	Keystone	-2
400-2802-01-00-20	Batteryholder / Batterycontact	Cambion	250
4814	Nylon Stand	Keystone	6000
482	Handle	Keystone	59
5004	Test Point	Keystone	2
5202	Batteryholder / Batterycontact	Keystone	14245
5203	Batteryholder / Batterycontact	Keystone	5030
5209	Batteryholder / Batterycontact	Keystone	10
5213	Batteryholder / Batterycontact	Keystone	217
5214	Batteryholder / Batterycontact	Keystone	1740
5218	Batteryholder / Batterycontact	Keystone	5
5221	Batteryholder / Batterycontact	Keystone	665
5224	Batteryholder / Batterycontact	Keystone	8264
56TR	Batteryholder / Batterycontact	Keystone	2500
591	Batteryholder / Batterycontact	Keystone	7882
635	Batteryholder / Batterycontact	Keystone	3
7170	Handle	Keystone	42
ABG-43	Battery Clip	MPD	3
BC1/3N-C-SM	Batteryholder / Batterycontact	MPD	800
BC3AAPC	Batteryholder / Batterycontact	MPD	99
BH212DW	Batteryholder / Batterycontact	MPD	60
BH28DL	Batteryholder / Batterycontact	MPD	2
BH2DW	Batteryholder / Batterycontact	MPD	60
BH3AAW	Batteryholder / Batterycontact	MPD	200
BHD-2	Batteryholder / Batterycontact	MPD	206
MBHCW	Batteryholder / Batterycontact	MPD	147
BCC	Batteryholder / Batterycontact	MPD	700
BK885	Batteryholder / Batterycontact	MPD	2632
ABG-44	Battery Clip	MPD	50
BC2032-E2	Batteryholder / Batterycontact	MPD	100
BC2AAAW	Batteryholder / Batterycontact	MPD	700
BC34AASF	Batteryholder / Batterycontact	MPD	5
BC4AAAW	Batteryholder / Batterycontact	MPD	120
BCAA	Batteryholder / Batterycontact	MPD	1708
BCAAAPC	Batteryholder / Batterycontact	MPD	300
BH13CW	Batteryholder / Batterycontact	MPD	150
BH16AAW	Batteryholder / Batterycontact	MPD	10
BH210CL	Batteryholder / Batterycontact	MPD	50
BH2AAAPC	Batteryholder / Batterycontact	MPD	5
BH2CL	Batteryholder / Batterycontact	MPD	100
BH2CW	Batteryholder / Batterycontact	MPD	100

BH2NW	Batteryholder / Batterycontact	MPD	150
BH4CW	Batteryholder / Batterycontact	MPD	80
BHAA-POL	Batteryholder / Batterycontact	MPD	200
BHDW	Batteryholder / Batterycontact	MPD	100
BHSD-2032-L	Batteryholder / Batterycontact	MPD	20
BHX1-1632-SM	Batteryholder / Batterycontact	MPD	937
BK-002	Batteryholder / Batterycontact	MPD	4
BK-204	Batteryholder / Batterycontact	MPD	20
BK-209	Batteryholder / Batterycontact	MPD	790
BK-228	Batteryholder / Batterycontact	MPD	720
BK-5091	Batteryholder / Batterycontact	MPD	500
BK-868	Batteryholder / Batterycontact	MPD	48
BK-870	Batteryholder / Batterycontact	MPD	5
BK-883	Batteryholder / Batterycontact	MPD	660
BK-885	Batteryholder / Batterycontact	MPD	5
BK-912	Batteryholder / Batterycontact	MPD	258
BK-1279	Batteryholder / Batterycontact	MPD	8
BLP2016SM-GTR	Batteryholder / Batterycontact	MPD	20
BSR	Batteryholder / Batterycontact	MPD	2420
BU2032SM	Batteryholder / Batterycontact	MPD	5
BU2450SM-JJ-GTR	Batteryholder / Batterycontact	MPD	4250
BVSD-2032-COVER	Batteryholder / Batterycontact	MPD	20
BVSD-2032-PC	Batteryholder / Batterycontact	MPD	40
CB-AA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AA-PC-POS	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-NEG	Batteryholder / Batterycontact	MPD	120
CB-AAA-PC-POS	Batteryholder / Batterycontact	MPD	120
CDRH6D23HP	inductive component	SUMIDA	2000
1RA1	switch	Honeywell	2
1PB5-T	Push Buttons	Honeywell	1
111SM2-T	Subminiature Basics	Honeywell	4
311SM6-T	Subminiature Basics	Honeywell	1
311SM1-T	Subminiature Basics	Honeywell	10
11SM3-S	Subminiature Basics	Honeywell	1
11SM1-N102	Subminiature Basics	Honeywell	6
111SM1-T	Subminiature Basics	Honeywell	3
311SM701-T	Subminiature Basics	Honeywell	2
311SM7604-H4	Subminiature Basics	Honeywell	3
311SM5-T	Subminiature Basics	Honeywell	5
311SM1-H2	Subminiature Basics	Honeywell	1
311SM702-T	Subminiature Basics	Honeywell	5
11SM23-H58	Subminiature Basics	Honeywell	3
311SM201	Subminiature Basics	Honeywell	3
311SM4-T	Subminiature Basics	Honeywell	6
311SM1	Subminiature Basics	Honeywell	2
311SM56	Subminiature Basics	Honeywell	1
311SM2-T	Subminiature Basics	Honeywell	1
311SX4-T	Subminiature Basics	Honeywell	1
11SM1	Subminiature Basics	Honeywell	10
1SM22	Subminiature Basics	Honeywell	5
411SM1	Subminiature Basics	Honeywell	2
11SM701-T	Subminiature Basics	Honeywell	5
1SM2-T	Subminiature Basics	Honeywell	5
11SM3-T	Subminiature Basics	Honeywell	3
41SM1-T	Subminiature Basics	Honeywell	3
11SM1-T24	Subminiature Basics	Honeywell	5
11SM244-T	Subminiature Basics	Honeywell	1
313SX2-T	Subminiature Basics	Honeywell	2
103MG5	Subminiature Basics	Honeywell	2
11SM23-T	Subminiature Basics	Honeywell	1300
11SM243-T	Subminiature Basics	Honeywell	45
11SM701-T	Subminiature Basics	Honeywell	75
11SX21-T	Subminiature Basics	Honeywell	2

12SM4-T	Subminiature Basics	Honeywell	359
1LS19-4PG	Industrial Limit Switches	Honeywell	14
1LS2-4PG	Industrial Limit Switches	Honeywell	6
1LS244-4PG	Industrial Limit Switches	Honeywell	9
1LS3-4PG	Industrial Limit Switches	Honeywell	7
1LS47-4PG	Industrial Limit Switches	Honeywell	2
1PA4	Industrial Limit Switches	Honeywell	10
1TB1-1	Large Basics	Honeywell	1
1TB1-3	Large Basics	Honeywell	6
1XE301	Aero Sealed Switch Legacy	Honeywell	5
201LS2-4	Industrial Limit Switches	Honeywell	1
20PCWHRC	20PC option part	Honeywell	16
2455R-00820688	Commercial Thermal	Honeywell	1
24PCFFA6G	PCB pressure sensor	Honeywell	3
24PCFFA6D	PCB pressure sensor	Honeywell	1
26PCCFA1G	PCB pressure sensor	Honeywell	1
26PCCFA6G	PCB pressure sensor	Honeywell	1
2MN1M/1PA22-4	Industrial Limit Switches	Honeywell	20
2MN8M/1PA39-4	Industrial Limit Switches	Honeywell	15
2SX1-T	Subminiature Basics	Honeywell	7
2TL1-1	Toggles & Rockers	Honeywell	1
2TL49-5K	Toggles & Rockers	Honeywell	1
2TL5-7	Toggles & Rockers	Honeywell	2
2TM-15T-7	Switch	Honeywell	57
311SM2-T	Subminiature Basics	Honeywell	318
311SM3-T	Subminiature Basics	Honeywell	4
311SM6-T	Subminiature Basics	Honeywell	3
311SM7-T	Subminiature Basics	Honeywell	18
311SX2-T	Subminiature Basics	Honeywell	1
313SX3-T	Subminiature Basics	Honeywell	1
3PA2	Industrial Limit Switches	Honeywell	3
411SM1	Subminiature Basics	Honeywell	3
4TL1-2	Toggles & Rockers	Honeywell	5
4TL1-8	Toggles & Rockers	Honeywell	1
4XE1	Aero Sealed Switch Legacy	Honeywell	1
511TS1-1	Toggles & Rockers	Honeywell	33
511TS1-2	Toggles & Rockers	Honeywell	1
5LS1-4PG	Industrial Limit Switches	Honeywell	3
5SE1	Subminiature Basics	Honeywell	7
5XE1-6	Aero Sealed Switch Legacy	Honeywell	1
5SE1-6N26	Aero Sealed Switch Legacy	Honeywell	12
6655-90980004	Thermistors	Honeywell	38
6655-91000001	Thermistors	Honeywell	48
6HM1-3	Aero Sealed Switch Legacy	Honeywell	2
6PA67-4	Industrial Limit Switches	Honeywell	10
8A-2011	Subminiature Basics	Honeywell	25
8C-1011	Subminiature Basics	Honeywell	91
8C-1012	Subminiature Basics	Honeywell	743
8P-1021-007	Industrial Limit Switches	Honeywell	3
8P-2011-007	Industrial Limit Switches	Honeywell	100
8Z-0081	Switch	Honeywell	120
8Z-0082	Switch	Honeywell	250
8Z-0083	Switch	Honeywell	176
8Z0152	Switch	Honeywell	476
904-VB1-PG	Switch	Honeywell	45
908AS-2RQ8	Switch	Honeywell	7
918PA1-PG	Switch	Honeywell	1
935PA1	Industrial Limit Switches	Honeywell	10
9PA16-4	Industrial Limit Switches	Honeywell	4
9PA33-4	Industrial Limit Switches	Honeywell	4
AML-22CBJ3AD	Push Buttons	Honeywell	20
AML-31FBA4AC01	Push Buttons	Honeywell	8
AML-35FBC7AC01	Push Buttons	Honeywell	146

AML-36FBC4AC01	Push Buttons	Honeywell	147
AML-52C10Y	Push Buttons	Honeywell	30
AML-54F10K	Push Buttons	Honeywell	17
AML-55N10TK	Push Buttons	Honeywell	199
AML-56N10RK	Push Buttons	Honeywell	275
AML-56N10TK	Push Buttons	Honeywell	121
AT-10063W	Subminiature Basics	Honeywell	100
AWM5102VN	Air Flow Sensor	Honeywell	4
AWM2150V	Air Flow Sensor	Honeywell	2
142PC05D	Pressure Sensor	Honeywell	1
BA-2RV22-A2	Large Basic Switch	Honeywell	2
BAF3-2RN18-LHPG	Large Basic Switch	Honeywell	7
BZ-22RM-A2	Large Basic Switch	Honeywell	10
BZ-2G-A2	Large Basic Switch	Honeywell	1
BZ-2R	Large Basic Switch	Honeywell	2
BZ-2R-A2	Large Basic Switch	Honeywell	4
BZ-2R55-A2	Large Basic Switch	Honeywell	1
BZ-2RD	Large Basic Switch	Honeywell	10
BZ-2RL	Large Basic Switch	Honeywell	1
BZ-2RL-2	Large Basic Switch	Honeywell	1
BZ-2RM-A2	Large Basic Switch	Honeywell	2
BZ-2RQ-18-J	Large Basic Switch	Honeywell	190
BZ-2RQ1-T04	Large Basic Switch	Honeywell	1
BZ-2RQ18M	Large Basic Switch	Honeywell	1
BZ-2RS	Large Basic Switch	Honeywell	31
BZ-2RW-80	Large Basic Switch	Honeywell	66
BZ-2RW-82	Large Basic Switch	Honeywell	34
BZ-2RW-825	Large Basic Switch	Honeywell	31
BZ-2RW-826	Large Basic Switch	Honeywell	171
BZ-2RW-826-A2	Large Basic Switch	Honeywell	2
BZ-2RW-84	Large Basic Switch	Honeywell	93
BZ-2RW82-A2	Large Basic Switch	Honeywell	1
BZ-2RW825-A2	Large Basic Switch	Honeywell	119
BZ-2RW826	Large Basic Switch	Honeywell	9
BZ-2RW8299-A2	Large Basic Switch	Honeywell	1
BZ-2RW855-A2	Large Basic Switch	Honeywell	20
BZ-R-A2	Large Basic Switch	Honeywell	2
BZ-R19	Large Basic Switch	Honeywell	1
BZE7-2RQ8-PG	Large Basic Switch	Honeywell	21
BZE7-2RQ81-PG	Large Basic Switch	Honeywell	16
BZE7-2RQ9-PG	Large Basic Switch	Honeywell	2
CLSA1CH	Current Sensor	Honeywell	2
CSDA1BC	Current Sensor	Honeywell	2
CSLE4AD	Current Sensor	Honeywell	2
CSNH151	Current Sensor	Honeywell	10
CSNP661	Current Sensor	Honeywell	2
DT-2RV-22-A7	Large Basic Switch	Honeywell	49
DTF2-2RN-RH	Large Basic Switch	Honeywell	4
HAFBSF0200C2AX5	Air Flow Sensor	Honeywell	10
HC4-DC48V	Relay	Honeywell	299
HEL-705-T-0-12-00	Temperatursensor	Honeywell	1
HIH-4031-001	Humidity Sensor	Honeywell	70
HMC1021Z	Mangentoresistive Sensor	Honeywell	1
HMC1051Z	Mangentoresistive Sensor	Honeywell	22
HMC1052	Mangentoresistive Sensor	Honeywell	1
HOA1404-002	Infrared Sensor	Honeywell	1
JE-1	Lever for switches	Honeywell	18
JE-5	Lever for switches	Honeywell	55
JS-2	Lever for switches	Honeywell	235
JS-2-C	Lever for switches	Honeywell	8
JS-220	Lever for switches	Honeywell	10
JS-246-C	Lever for switches	Honeywell	71
JS-31	Lever for switches	Honeywell	2

JS-33	Lever for switches	Honeywell	3
JS-5J	Lever for switches	Honeywell	3
JS-7	Lever for switches	Honeywell	58
JV-9020-C	Lever for switches	Honeywell	25
JX-20	Lever for switches	Honeywell	10
JX-206	Lever for switches	Honeywell	4
JX-4	Lever for switches	Honeywell	3
JX-47	Lever for switches	Honeywell	211
JX-95	Lever for switches	Honeywell	2
LML-2-S	Foot Switch	Honeywell	10
M922AA1Y-B4P-L	switch	Honeywell	1
M5594/1-2	Toggles & Rockers	Honeywell	5
M5594/1-3	Toggles & Rockers	Honeywell	22
MT-4RL2	Large Basic Switch	Honeywell	5
PC-10182	20PC option part	Honeywell	65
PC-10198	20PC option part	Honeywell	27
SS-12125	Hall Sensor	Honeywell	1
SS496A1	Hall Sensor	Honeywell	21
SS496A1-S	Hall Sensor	Honeywell	4
SS496A1-SP	Hall Sensor	Honeywell	4
SS94A1F	Hall Sensor	Honeywell	2
SSCDANN100MGAA3	PCB Pressure Sensor	Honeywell	2
SSCDANN100MGAA5	PCB Pressure Sensor	Honeywell	2
SSCSRNN400MGAA5	PCB Pressure Sensor	Honeywell	2
SSCSRNN400MGAA5	PCB Pressure Sensor	Honeywell	2
V3 9101M 11K	Micro Switch	Honeywell	1
V3 9101M-D18	Micro Switch	Honeywell	1
V3 9101M11-D18	Micro Switch	Honeywell	1
V3 9132M20	Micro Switch	Honeywell	1
V3 9245M	Micro Switch	Honeywell	2
V3 99128 M9 D18	Micro Switch	Honeywell	1
V3 99245M D18	Micro Switch	Honeywell	1
V3-101-D9	Micro Switch	Honeywell	1
V3-1101-D8	Micro Switch	Honeywell	39
V3-5000-S	Micro Switch	Honeywell	1
V3-5100	Micro Switch	Honeywell	1
V3-9001M-D18	Micro Switch	Honeywell	2
V3-9001M-F	Micro Switch	Honeywell	2
V3-9019M	Micro Switch	Honeywell	167
V3-9023M	Micro Switch	Honeywell	6
V3-9043	Micro Switch	Honeywell	1
V3-9101M-F	Micro Switch	Honeywell	9
V3-9115M	Micro Switch	Honeywell	613
V3-9115M11	Micro Switch	Honeywell	14
V309101M 11K	Micro Switch	Honeywell	1
V399246M	Micro Switch	Honeywell	4
V3L09101M11K	Micro Switch	Honeywell	1
V3L1122-D8	Micro Switch	Honeywell	3
V3LB9101M	Micro Switch	Honeywell	5
V3LD9101M20D18	Micro Switch	Honeywell	1
V3LE99123	Micro Switch	Honeywell	1
V4-14	Micro Switch	Honeywell	2
V5C010BB	Micro Switch	Honeywell	3
V5C010BB1D	Micro Switch	Honeywell	35
V7-3S17D8-048	Micro Switch	Honeywell	2
V91031CB	Micro Switch	Honeywell	6
V92031BB	Micro Switch	Honeywell	10
VR5C010BB3	Micro Switch	Honeywell	1
XN300736V3	XN300736V3	Honeywell	7
ZM50E70A01	XN300736V3	Honeywell	10
1HT1	High Temperature Switch	Honeywell	16
GMS10RVS	Oxygen Sensor	Honeywell	10
CH291-1220LF/T&R	Batteryholder / Batterycontact	Comfortable	10000

CH74-2032LF	Batteryholder / Batterycontact	Comfortable	10000
B318D	Batteryholder / Batterycontact	Comfortable	20000
B404B	Batteryholder / Batterycontact	Comfortable	500
BH131D	Batteryholder / Batterycontact	Comfortable	2400
BH432	Batteryholder / Batterycontact	Comfortable	30022
BS-IR-150	Batteryholder / Batterycontact	Comfortable	21500
BS-TR-150	Batteryholder / Batterycontact	Comfortable	4100
1LS1-4PGN159	Industrial Limit Switches	Honeywell	1
19C200PA1K	Pressure Sensor	Honeywell	3
400-2801-01-00-20	Batteryholder / Batterycontact	Cambion	750
400-1803-01-00-20	Batteryholder / Batterycontact	Cambion	250
400-2800-01-00-20	Batteryholder / Batterycontact	Cambion	350
BX0013-1	Batteryholder / Batterycontact	bulgin	572
BX0035	Batteryholder / Batterycontact	bulgin	100
BX0035AU	Batteryholder / Batterycontact	bulgin	100
43191679-002	Industry products	Honeywell-Fema	4
AF20-B65	Industry products	Honeywell-Fema	1
BA295CS-11/4A	Industry products	Honeywell-Fema	1
BA295S-1/2A	Industry products	Honeywell-Fema	1
D06FI-1B	Industry products	Honeywell-Fema	8
D06FN-1/2B	Industry products	Honeywell-Fema	2
DCM10-HNY	Industry products	Honeywell-Fema	2
DCM6	Industry products	Honeywell-Fema	28
DWR6	Industry products	Honeywell-Fema	4
DWR6-203	Industry products	Honeywell-Fema	2
ES06F-1/2A	Industry products	Honeywell-Fema	1
FK06-1/2AA	Industry products	Honeywell-Fema	1
KH11AS-1/2	Industry products	Honeywell-Fema	1
M07M-A4	Industry products	Honeywell-Fema	1
ML6421B3012	Industry products	Honeywell-Fema	3
N1024	Industry products	Honeywell-Fema	1
N2024-SW2	Industry products	Honeywell-Fema	2
S10230-2POS-SW2	Industry products	Honeywell-Fema	3
V5329C1018	Industry products	Honeywell-Fema	1
VNM111	Industry products	Honeywell-Fema	1
VSOE-215-1.6	Industry products	Honeywell-Fema	4
VST06-1/2A	Industry products	Honeywell-Fema	1
ZR06K	Industry products	Honeywell-Fema	1
C12000B	solder test point	Nicomatic	14000
25ET61-T	Aero Sealed Switch Legacy	Honeywell	1
M5594/1-2	Aero Sealed Switch Legacy	Honeywell	5
5851949	connector	Keystone	28
4NW3-1	numeric key 1-4	Honeywell	1
V4-14	switch	Honeywell	1
MSU1	switch	Harting	1
3557-15	fuseholder	Keystone	1000
GTN1A131	speed sensor	Honeywell	25
GTN1A231	speed sensor	honeywell	23
TB-65-0.6-1.5S/90mm	thermoelectric cooler	Kryotherm	100
TB-65-0.6-1.5S/90mm	thermoelectric cooler	ECOGEN Technology	100
40PC100G2A	Pressure Sensor	Honeywell	3
40PC015G2A	Pressure Sensor	Honeywell	1
142PC15AL	Pressure Sensor	Honeywell	1
163PC01D75	Pressure Sensor	honeywell	1
ABP2MRRT005PD2A3XX	Pressure Sensor	honeywell	5
LSZ1JGA	head with (plastic) actuator	honeywell	2
LSZ1JCGN	head with (metall) actuator	honeywell	2
LSYJC1A-7N	sealed switch	honeywell	2
111SM2-T	Subminiature Basics	Honeywell	29
11SM401-T	Subminiature Basics	Honeywell	139
11TW1-1L	Toggles & Rockers	Honeywell	31
11TW1-3	Toggles & Rockers	Honeywell	24
11TW1-8	Toggles & Rockers	Honeywell	400

12SX1-T	Aero Sealed Switch Legacy	Honeywell	210
12TW1-3	Toggles & Rockers	Honeywell	50
12TW1-70	Toggles & Rockers	Honeywell	170
12TW1-8	Toggles & Rockers	Honeywell	50
14CE1-3A	Industrial Limit Switches	Honeywell	90
14CE18-6AH	Industrial Limit Switches	Honeywell	5
18PA1-4PG	Industrial Limit Switches	Honeywell	14
1HT1	High Temperature Switch	Honeywell	153
1LS243-4PG	Industrial Limit Switches	Honeywell	15
1LS244-4PG	Industrial Limit Switches	Honeywell	4
1SE1	Aero Sealed Switch Legacy	Honeywell	10
1SX1-T	Aero Sealed Switch Legacy	Honeywell	200
1TL1-3	Toggles & Rockers	Honeywell	64
1TL1-7	Toggles & Rockers	Honeywell	4
1XE1-T	Aero Sealed Switch Legacy	Honeywell	14
201LS3-4	Industrial Limit Switches	Honeywell	1
208LS1-4	Industrial Limit Switches	Honeywell	52
23SX39-T	Aero Sealed Switch Legacy	Honeywell	150
2455R--90820461	Thermostat	Honeywell	100
2455RM-90820468	Thermostat	Honeywell	1200
25ET61-S	Aero Sealed Switch Legacy	Honeywell	2
26PC05SMT	Pressure Sensor	Honeywell	50
26PC15SMT	Pressure Sensor	Honeywell	751
26PCBFA6G	Pressure Sensor	honeywell	218
26PCCFA6G	Pressure Sensor	Honeywell	682
26PCCFH6G	Pressure Sensor	Honeywell	5
26PCFFA6D	Pressure Sensor	Honeywell	10
26PCFFA6G	Pressure Sensor	Honeywell	550
26PCGFA6G	Pressure Sensor	Honeywell	6
2NT1-7	Toggles & Rockers	Honeywell	10
2SS52M-S-TR	Hallsensor	honeywell	1000
2TL1-7	Toggles & Rockers	Honeywell	10
2TP4-5	Toggles & Rockers	Honeywell	5
3HT1	High Temperature Switch	honeywell	74
4AV19F	hallsensor	Honeywell	7
4TL1-12	Toggles & Rockers	Honeywell	64
5PA2	Industrial Limit Switches	Honeywell	102
5SE1-6N26	Aero Sealed Switch Legacy	Honeywell	10
5SE1	Aero Sealed Switch Legacy	Honeywell	2
6HM1-1	Aero Sealed Switch Legacy	Honeywell	2
8LS1-4PG	Industrial Limit Switches	Honeywell	31
908AS-2RN	Industrial Limit Switches	Honeywell	25
91SE3-3	Aero Sealed Switch Legacy	Honeywell	23
9PA58-4	Industrial Limit Switches	Honeywell	4
ABPDRRT015PG3D3	Basic Pressure Sensor	Honeywell	600
ABPLLNT010BGAA5	Basic Pressure Sensor	Honeywell	200
ASDXAVX015PGAAS	Basic Pressure Sensor	Honeywell	400
ASDXRRX005NDAA5	Basic Pressure Sensor	Honeywell	3
AWM2100V	Air Flow Sensor	Honeywell	40
AWM3300V	Air Flow Sensor	Honeywell	44
AWM3303V	Air Flow Sensor	Honeywell	20
AWM42150VH	Air Flow Sensor	Honeywell	7
AWM43300V	Air Flow Sensor	Honeywell	33
AWM43600V2	Air Flow Sensor	honeywell	32
AWM5102VN	Air Flow Sensor	Honeywell	22
AWM5103VN	Air Flow Sensor	Honeywell	3
AWM5104VC	Air Flow Sensor	Honeywell	100
AWM720P1	Air Flow Sensor	Honeywell	27
BZ-2RD-A2	Large Basic Switch	Honeywell	105
BZ-2RQ1-A2	Large Basic Switch	Honeywell	164
BZ-2RQ18-A2	Large Basic Switch	Honeywell	481
BZ-2RW80-A2	Large Basic Switch	Honeywell	327
BZ-2RW82-A2	Large Basic Switch	Honeywell	620

BZ-5RW822-A2-F2	Large Basic Switch	honeywell	798
BZ-R	Large Basic Switch	honeywell	40
BZ-R7216	Large Basic Switch	Honeywell	4
C06-0800-000	Co2 sensor	Honeywell	10
C06-0801-000	Co2 sensor	Honeywell	10
CSNS300M	Current Sensor	Honeywell	5
CSNT651	Current Sensor	Honeywell	70
FSS015WNGB	force sensor	Honeywell	121
GLCC01E7B	Industrial Limit Switches	Honeywell	15
HAFBSF0200C4AX3	Air Flow Sensor	Honeywell	500
HAFBSS0200C4AX3	Air Flow Sensor	Honeywell	1
HEL-705-T-0-12-00	Temperature Sensor	Honeywell	486
HEL-705-U-0-12-00	Temperature Sensor	Honeywell	269
HEL-707-T-0-12-00	Temperature Sensor	Honeywell	35
HIH-4000-002	Humidity Sensor	honeywell	100
HIH-4010-004	Humidity Sensor	Honeywell	95
HIH-4021-001	Humidity Sensor	honeywell	25
HIH-4031-001	Humidity Sensor	honeywell	45
HIH-4602-L-CP	Humidity Sensor	honeywell	1212
HIH-5030-001	Humidity Sensor	honeywell	11
HIH-5031-001	Humidity Sensor	honeywell	11
HIH-8131-021-001	Humidity Sensor	Honeywell	3
HMC1021S	magneto resistive sensor	Honeywell	15
HMC1022	magneto resistive sensor	honeywell	107
HMC1051ZRC	magneto resistive sensor	Honeywell	3
JE-13	Lever for switches	honeywell	10
JE-N30	Lever for switches	honeywell	25
JS-151	Lever for switches	Honeywell	3
LLN865172-1	Lequid level sensor	honeywell	1
LSYKC1ADD-8C-C	Industrial Limit Switches	Honeywell	8
MIPFG2XX016BACHX	pressure sensor	honeywell	2
MPRLS0025PA00001A	pressure sensor	Honeywell	2100
NBPLANNO30PAUNV	pressure sensor	Honeywell	432
NGCPB10AX01B	pressure sensor	honeywell	1
RTY120HVEAX	angle sensor	honeywell	100
SCX030DNC	pressure sensor	honeywell	1
SCXL004DN	pressure sensor	honeywell	1
SDX05D4	pressure sensor	honeywell	50
SDX30A4	pressure sensor	honeywell	24
SDX30D4	pressure sensor	honeywell	25
SR17C-J6	Hallsensor	honeywell	24
SS41	Hallsensor	honeywell	2199
SS411A	Hallsensor	honeywell	48
SS413A	Hallsensor	honeywell	1000
SS443A	Hallsensor	honeywell	550
SS466A	Hallsensor	honeywell	474
SS495A	Hallsensor	honeywell	1800
SS495A1	Hallsensor	honeywell	4
SS495B	Hallsensor	honeywell	15
SS549AT	Hallsensor	Honeywell	5000
SS59ET	Hallsensor	Honeywell	796
SSCDANN015PGAA5	pressure sensor	Honeywell	100
SSCDANN400MGAA5	pressure sensor	honeywell	100
SSCDRRN004NDAA5	pressure sensor	honeywell	6
SSCSAAN004ND2A5	pressure sensor	honeywell	5
TBPLLNN015PGUCV	pressure sensor	honeywell	581
V15W-WZ200A02-W2	pressure sensor	honeywell	300
V15W-WZ200A04-W3	Micro Switch	honeywell	625
V7-2S17D8-201	Micro Switch	honeywell	42
1012	batteryholder / Batterycontact	Keystone	80
1018	batteryholder / Batterycontact	Keystone	758
1020-1	batteryholder / Batterycontact	Keystone	79
1020	batteryholder / Batterycontact	Keystone	155

1023	batteryholder / Batterycontact	Keystone	375
1024	batteryholder / Batterycontact	Keystone	33
1025-7	batteryholder / Batterycontact	Keystone	3200
1025	Batteryholder / Batterycontact	Keystone	151
1027	Batteryholder / Batterycontact	Keystone	93
1028	Batteryholder / Batterycontact	Keystone	1897
1028 C	Batteryholder / Batterycontact	Keystone	5760
1029	Batteryholder / Batterycontact	Keystone	750
1029 C	Batteryholder / Batterycontact	Keystone	339
1029LC	Batteryholder / Batterycontact	Keystone	4950
103	Batteryholder / Batterycontact	Keystone	4033
1042	Batteryholder / Batterycontact	Keystone	200
1042P	Batteryholder / Batterycontact	Keystone	61
1043	Batteryholder / Batterycontact	Keystone	75
1043P	Batteryholder / Batterycontact	Keystone	99
1047	Batteryholder / Batterycontact	Keystone	300
1048	Batteryholder / Batterycontact	Keystone	220
1049	Batteryholder / Batterycontact	Keystone	183
105	Batteryholder / Batterycontact	Keystone	225
1053	Batteryholder / Batterycontact	Keystone	20
1056TR	Batteryholder / Batterycontact	Keystone	3
1058	Batteryholder / Batterycontact	Keystone	1053
1059	Batteryholder / Batterycontact	Keystone	212
106	Batteryholder / Batterycontact	Keystone	4
1060	Batteryholder / Batterycontact	Keystone	349
1061	Batteryholder / Batterycontact	Keystone	154
1065	Batteryholder / Batterycontact	Keystone	4297
1066	Batteryholder / Batterycontact	Keystone	4179
1067	Batteryholder / Batterycontact	Keystone	511
1068	Batteryholder / Batterycontact	Keystone	197
1069	Batteryholder / Batterycontact	Keystone	51
107	Batteryholder / Batterycontact	Keystone	293
1070	Batteryholder / Batterycontact	Keystone	433
1076-1	Batteryholder / Batterycontact	Keystone	86
108-2	Batteryholder / Batterycontact	Keystone	33164
108-C	Batteryholder / Batterycontact	Keystone	609
108	Batteryholder / Batterycontact	Keystone	8199
1081	Batteryholder / Batterycontact	Keystone	18
1088	Batteryholder / Batterycontact	Keystone	2
1095P	Batteryholder / Batterycontact	Keystone	50
1097	Batteryholder / Batterycontact	Keystone	50
1097P	Batteryholder / Batterycontact	Keystone	25
1098	Batteryholder / Batterycontact	Keystone	80
1098P	Batteryholder / Batterycontact	Keystone	100
1101	Batteryholder / Batterycontact	Keystone	80
1102	Batteryholder / Batterycontact	Keystone	41
1106	Batteryholder / Batterycontact	Keystone	173
1107	Batteryholder / Batterycontact	Keystone	446
1108	Batteryholder / Batterycontact	Keystone	100
1109	Batteryholder / Batterycontact	Keystone	39
112	Batteryholder / Batterycontact	Keystone	618
117-LABEL	Batteryholder / Batterycontact	Keystone	351
120	Batteryholder / Batterycontact	Keystone	55
1294	Batteryholder / Batterycontact	Keystone	369
1295	Batteryholder / Batterycontact	Keystone	800
138	Batteryholder / Batterycontact	Keystone	101
146	Batteryholder / Batterycontact	Keystone	361
149	Batteryholder / Batterycontact	Keystone	60
151	Batteryholder / Batterycontact	Keystone	76
152	Batteryholder / Batterycontact	Keystone	28
175	Batteryholder / Batterycontact	Keystone	204
202	Batteryholder / Batterycontact	Keystone	73854
204	Batteryholder / Batterycontact	Keystone	70531

209	Batteryholder / Batterycontact	Keystone	19310
210	Batteryholder / Batterycontact	Keystone	8554
211	Batteryholder / Batterycontact	Keystone	14
211 D	Batteryholder / Batterycontact	Keystone	950
228	Batteryholder / Batterycontact	Keystone	6686
230-1	Batteryholder / Batterycontact	Keystone	50
238	Batteryholder / Batterycontact	Keystone	6285
2413	Batteryholder / Batterycontact	Keystone	20
2460RB	Batteryholder / Batterycontact	Keystone	497
2468	Batteryholder / Batterycontact	Keystone	153
261	Batteryholder / Batterycontact	Keystone	132
269	Batteryholder / Batterycontact	Keystone	121
288	Batteryholder / Batterycontact	Keystone	5820
290	Batteryholder / Batterycontact	Keystone	1400
291	Batteryholder / Batterycontact	Keystone	4464
295	Batteryholder / Batterycontact	Keystone	1554
296	Batteryholder / Batterycontact	Keystone	2706
2988	Batteryholder / Batterycontact	Keystone	21
2990	Batteryholder / Batterycontact	Keystone	696
2991	Batteryholder / Batterycontact	Keystone	6060
2991TR	Batteryholder / Batterycontact	Keystone	36000
2992TR	Batteryholder / Batterycontact	Keystone	31395
2994	Batteryholder / Batterycontact	Keystone	2
2996	Batteryholder / Batterycontact	Keystone	1968
2998	Batteryholder / Batterycontact	Keystone	557
2999	Batteryholder / Batterycontact	Keystone	450
3001	Batteryholder / Batterycontact	Keystone	72
3002	Batteryholder / Batterycontact	Keystone	352
3002TR	Batteryholder / Batterycontact	Keystone	48500
3003	Batteryholder / Batterycontact	Keystone	10869
3005	Batteryholder / Batterycontact	Keystone	923
3006TR	Batteryholder / Batterycontact	Keystone	800
3008	Batteryholder / Batterycontact	Keystone	791
3008TR	Batteryholder / Batterycontact	Keystone	3000
3009	Batteryholder / Batterycontact	Keystone	188
3012	Batteryholder / Batterycontact	Keystone	402
3020	Batteryholder / Batterycontact	Keystone	208
3022	Batteryholder / Batterycontact	Keystone	14
3026	Batteryholder / Batterycontact	Keystone	102
3030	Batteryholder / Batterycontact	Keystone	2
3030TR	Batteryholder / Batterycontact	Keystone	4
3046	Batteryholder / Batterycontact	Keystone	52
3348	Batteryholder / Batterycontact	Keystone	1000
3557-2	Batteryholder / Batterycontact	Keystone	4221
4814	Batteryholder / Batterycontact	Keystone	5000
500	Batteryholder / Batterycontact	Keystone	408
5000	Batteryholder / Batterycontact	Keystone	6690
5001	Batteryholder / Batterycontact	Keystone	838
5006	Batteryholder / Batterycontact	Keystone	12231
5007	Batteryholder / Batterycontact	Keystone	18956
5011	Batteryholder / Batterycontact	Keystone	500
5016	Batteryholder / Batterycontact	Keystone	3000
5017	Batteryholder / Batterycontact	Keystone	25
502	Batteryholder / Batterycontact	Keystone	4849
504TR	Batteryholder / Batterycontact	Keystone	2700
5201	Batteryholder / Batterycontact	Keystone	21442
5202	Batteryholder / Batterycontact	Keystone	4184
5203	Batteryholder / Batterycontact	Keystone	5088
5204	Batteryholder / Batterycontact	Keystone	4
5205	Batteryholder / Batterycontact	Keystone	102
5212	Batteryholder / Batterycontact	Keystone	2541
5213	Batteryholder / Batterycontact	Keystone	1752
5214	Batteryholder / Batterycontact	Keystone	1740

5218	Batteryholder / Batterycontact	Keystone	5
5221	Batteryholder / Batterycontact	Keystone	378
5222	Batteryholder / Batterycontact	Keystone	16
5223	Batteryholder / Batterycontact	Keystone	981
5224	Batteryholder / Batterycontact	Keystone	323
5225	Batteryholder / Batterycontact	Keystone	2418
5226	Batteryholder / Batterycontact	Keystone	11669
5230	Batteryholder / Batterycontact	Keystone	2589
5231	Batteryholder / Batterycontact	Keystone	1163
5231TR	Batteryholder / Batterycontact	Keystone	2000
5233	Batteryholder / Batterycontact	Keystone	83
54/18650	Batteryholder / Batterycontact	Keystone	2679
5851949	Batteryholder / Batterycontact	Keystone	28
590	Batteryholder / Batterycontact	Keystone	12500
591	Batteryholder / Batterycontact	Keystone	7882
593	Batteryholder / Batterycontact	Keystone	186
594	Batteryholder / Batterycontact	Keystone	500
595	Batteryholder / Batterycontact	Keystone	3252
596	Batteryholder / Batterycontact	Keystone	12500
6039	Batteryholder / Batterycontact	Keystone	18
628	Batteryholder / Batterycontact	Keystone	5691
629	Batteryholder / Batterycontact	Keystone	4
635	Batteryholder / Batterycontact	Keystone	3
7143	Batteryholder / Batterycontact	Keystone	1071
7170	Batteryholder / Batterycontact	Keystone	22
82	Batteryholder / Batterycontact	Keystone	20130
9-5230-191	Batteryholder / Batterycontact	Keystone	13167
92	Batteryholder / Batterycontact	Keystone	1435
ROB-C-14862-SOM	Batteryholder / Batterycontact	Keystone	6600
ROB9-1043-2P	Batteryholder / Batterycontact	Keystone	500
ROB9-210BEC	Batteryholder / Batterycontact	Keystone	790
ROSS-82-AU-V2	Batteryholder / Batterycontact	Keystone	20
B402	Batteryholder / Batterycontact / Batteryclip	Keystone	490
ROB1BH-331-2ATH120MM	Batteryholder / Batterycontact / Batteryclip	Comfortable	14
ROB2032HP-310	Batteryholder / Batterycontact / Batteryclip	Comfortable	5000
ROB404B2014	Batteryholder / Batterycontact / Batteryclip	Comfortable	500
ROBBH-232D	Batteryholder / Batterycontact / Batteryclip	Comfortable	1000
ROBBH-331-3A	Batteryholder / Batterycontact / Batteryclip	Comfortable	400
ROBBH-431-1ATH	Batteryholder / Batterycontact / Batteryclip	Comfortable	300
ROBBH111-1D	Batteryholder / Batterycontact / Batteryclip	Comfortable	500
ROBBH121-1B	Batteryholder / Batterycontact / Batteryclip	Comfortable	500
ROBBH131D	Batteryholder / Batterycontact / Batteryclip	Comfortable	2400
ROBBH142-1B	Batteryholder / Batterycontact / Batteryclip	Comfortable	500
ROBBH161BMOD	Batteryholder / Batterycontact / Batteryclip	Comfortable	796
ROBBH221-1D	Batteryholder / Batterycontact / Batteryclip	Comfortable	500
ROBBH243B	Batteryholder / Batterycontact / Batteryclip	Comfortable	520
ROBBH261B	Batteryholder / Batterycontact / Batteryclip	Comfortable	500
ROBBH321-2P	Batteryholder / Batterycontact / Batteryclip	Comfortable	5400
ROBBH331-3B	Batteryholder / Batterycontact / Batteryclip	Comfortable	2000
ROBBH331-3D	Batteryholder / Batterycontact / Batteryclip	Comfortable	1000
ROBBH3313P	Batteryholder / Batterycontact / Batteryclip	Comfortable	1
ROBBH411P	Batteryholder / Batterycontact / Batteryclip	Comfortable	2000
ROBBH421-3A-70MM	Batteryholder / Batterycontact / Batteryclip	Comfortable	4248
ROBBH421-3A	Batteryholder / Batterycontact / Batteryclip	Comfortable	10000
ROBBH421-4D	Batteryholder / Batterycontact / Batteryclip	Comfortable	800
ROBBH441ATH	Batteryholder / Batterycontact / Batteryclip	Comfortable	3000
ROBBH441D	Batteryholder / Batterycontact / Batteryclip	Comfortable	34
ROBBH9V-3A	Batteryholder / Batterycontact / Batteryclip	Comfortable	300
ROBCR1235M-TR	Batteryholder / Batterycontact / Batteryclip	Comfortable	5
ROBSFIC-110	Batteryholder / Batterycontact / Batteryclip	Comfortable	900
ROBSHIC-150-3,5	Batteryholder / Batterycontact / Batteryclip	Comfortable	1140
ROBSHIC-150-INVERSE	Batteryholder / Batterycontact / Batteryclip	Comfortable	98
ROBSHIC-150	Batteryholder / Batterycontact / Batteryclip	Comfortable	8012

ROBSHC-220	Batteryholder / Batterycontact / Batteryclip	Comfortable	800
ROBSHTC-150	Batteryholder / Batterycontact / Batteryclip	Comfortable	1113
ROBSHTRC-150	Batteryholder / Batterycontact / Batteryclip	Comfortable	100
ROBSHTRCT-150	Batteryholder / Batterycontact / Batteryclip	Comfortable	11
172-4204	Batteryholder / Batterycontact / Batteryclip	MPD	10
ABG-44	Batteryholder / Batterycontact / Batteryclip	MPD	55
BA2032	Batteryholder / Batterycontact / Batteryclip	MPD	598
BA2032SM	Batteryholder / Batterycontact / Batteryclip	MPD	550
BA3AAPC-UL94V-0	Batteryholder / Batterycontact / Batteryclip	MPD	95
BA4AAPC	Batteryholder / Batterycontact / Batteryclip	MPD	127
BC3AAPC	Batteryholder / Batterycontact / Batteryclip	MPD	99
BC4AAW	Batteryholder / Batterycontact / Batteryclip	MPD	14
BH 1/3N-C	Batteryholder / Batterycontact / Batteryclip	MPD	55
BH 2N	Batteryholder / Batterycontact / Batteryclip	MPD	60
BH212DW	Batteryholder / Batterycontact / Batteryclip	MPD	20
BH26AASF	Batteryholder / Batterycontact / Batteryclip	MPD	599
BH26DW	Batteryholder / Batterycontact / Batteryclip	MPD	76
BH2AAAW	Batteryholder / Batterycontact / Batteryclip	MPD	83
BH2AAW	Batteryholder / Batterycontact / Batteryclip	MPD	117
BH2DW	Batteryholder / Batterycontact / Batteryclip	MPD	110
BH32T-C	Batteryholder / Batterycontact / Batteryclip	MPD	3000
BH3AAW	Batteryholder / Batterycontact / Batteryclip	MPD	200
BH3DW	Batteryholder / Batterycontact / Batteryclip	MPD	100
BH48DW	Batteryholder / Batterycontact / Batteryclip	MPD	116
BH4DW	Batteryholder / Batterycontact / Batteryclip	MPD	50
BHD-2	Batteryholder / Batterycontact / Batteryclip	MPD	56
B55 VERTICAL	Batteryholder / Batterycontact / Batteryclip	MPD	21850
MBHCW	Batteryholder / Batterycontact / Batteryclip	MPD	154
BCC	Batteryholder / Batterycontact / Batteryclip	MPD	700
BK885	Batteryholder / Batterycontact / Batteryclip	MPD	6147
ABG-43	Batteryholder / Batterycontact / Batteryclip	MPD	53
ABG-44	Batteryholder / Batterycontact / Batteryclip	MPD	50
ABG-47	Batteryholder / Batterycontact / Batteryclip	MPD	207
BA3AAW	Batteryholder / Batterycontact / Batteryclip	MPD	50
BA4AAW	Batteryholder / Batterycontact / Batteryclip	MPD	295
BA4D-S	Batteryholder / Batterycontact / Batteryclip	MPD	550
BC-2003	Batteryholder / Batterycontact / Batteryclip	MPD	1000
BC2032-E2	Batteryholder / Batterycontact / Batteryclip	MPD	2800
BC2032-F1	Batteryholder / Batterycontact / Batteryclip	MPD	300
BC22AAW	Batteryholder / Batterycontact / Batteryclip	MPD	200
BC2AAAL	Batteryholder / Batterycontact / Batteryclip	MPD	1300
BC2AAPC	Batteryholder / Batterycontact / Batteryclip	MPD	5373
BC2AAAW	Batteryholder / Batterycontact / Batteryclip	MPD	700
BC2AAPC	Batteryholder / Batterycontact / Batteryclip	MPD	1004
BC3AAAW	Batteryholder / Batterycontact / Batteryclip	MPD	100
BC4AAAW	Batteryholder / Batterycontact / Batteryclip	MPD	322
BC4AAB	Batteryholder / Batterycontact / Batteryclip	MPD	2240
BCAAAW	Batteryholder / Batterycontact / Batteryclip	MPD	101
BCAAW	Batteryholder / Batterycontact / Batteryclip	MPD	177
BH-20H-1T	Batteryholder / Batterycontact / Batteryclip	MPD	10
BH1000G	Batteryholder / Batterycontact / Batteryclip	MPD	800
BH123A	Batteryholder / Batterycontact / Batteryclip	MPD	60200
BH13CW	Batteryholder / Batterycontact / Batteryclip	MPD	165
BH14AASF	Batteryholder / Batterycontact / Batteryclip	MPD	302
BH210CL	Batteryholder / Batterycontact / Batteryclip	MPD	400
BH210CW	Batteryholder / Batterycontact / Batteryclip	MPD	80
BH223L	Batteryholder / Batterycontact / Batteryclip	MPD	56
BH22CL	Batteryholder / Batterycontact / Batteryclip	MPD	51
BH26CW	Batteryholder / Batterycontact / Batteryclip	MPD	75
BH28AAAW	Batteryholder / Batterycontact / Batteryclip	MPD	200
BH2CL	Batteryholder / Batterycontact / Batteryclip	MPD	100
BH2CW	Batteryholder / Batterycontact / Batteryclip	MPD	225
BH4NW	Batteryholder / Batterycontact / Batteryclip	MPD	100

BH600-5.8-G	Batteryholder / Batterycontact / Batteryclip	MPD	640
BH600	Batteryholder / Batterycontact / Batteryclip	MPD	400
BH908T-C	Batteryholder / Batterycontact / Batteryclip	MPD	800
BH9VW	Batteryholder / Batterycontact / Batteryclip	MPD	5
BHAA-3-G	Batteryholder / Batterycontact / Batteryclip	MPD	3
BHAA-POL	Batteryholder / Batterycontact / Batteryclip	MPD	200
BHC-2	Batteryholder / Batterycontact / Batteryclip	MPD	300
BHC-POL	Batteryholder / Batterycontact / Batteryclip	MPD	63
BHSD-2032-SM	Batteryholder / Batterycontact / Batteryclip	MPD	4400
BHSD1225COVER	Batteryholder / Batterycontact / Batteryclip	MPD	130
BHX1-1632-SCHUB	Batteryholder / Batterycontact / Batteryclip	MPD	53
BHX1-1632-SM	Batteryholder / Batterycontact / Batteryclip	MPD	696
BHX1-2032-SM	Batteryholder / Batterycontact / Batteryclip	MPD	5833
BHX1-2325-PC	Batteryholder / Batterycontact / Batteryclip	MPD	400
BHX1-2325-SM	Batteryholder / Batterycontact / Batteryclip	MPD	850
BHX1-2430-PC	Batteryholder / Batterycontact / Batteryclip	MPD	95
BHX1-2430-SM	Batteryholder / Batterycontact / Batteryclip	MPD	250
BHX1-2450-PC	Batteryholder / Batterycontact / Batteryclip	MPD	50
BHX2-2032-PC	Batteryholder / Batterycontact / Batteryclip	MPD	81
BI-2032	Batteryholder / Batterycontact / Batteryclip	MPD	14710
BI-UM-1-2	Batteryholder / Batterycontact / Batteryclip	MPD	691
BI-UM-3-4	Batteryholder / Batterycontact / Batteryclip	MPD	70000
BK-002	Batteryholder / Batterycontact / Batteryclip	MPD	35
BK-030	Batteryholder / Batterycontact / Batteryclip	MPD	180
BK-1264-PC8	Batteryholder / Batterycontact / Batteryclip	MPD	100
BK-1280-PC6	Batteryholder / Batterycontact / Batteryclip	MPD	200
BK-18650-PC4	Batteryholder / Batterycontact / Batteryclip	MPD	55
BK-18650-PC6	Batteryholder / Batterycontact / Batteryclip	MPD	105
BK-18650-PC8	Batteryholder / Batterycontact / Batteryclip	MPD	118
BK-204	Batteryholder / Batterycontact / Batteryclip	MPD	20
BK-209	Batteryholder / Batterycontact / Batteryclip	MPD	569
BK-228	Batteryholder / Batterycontact / Batteryclip	MPD	720
BK-5058	Batteryholder / Batterycontact / Batteryclip	MPD	8200
BK-5091	Batteryholder / Batterycontact / Batteryclip	MPD	500
BK-6049	Batteryholder / Batterycontact / Batteryclip	MPD	425
BK-6113	Batteryholder / Batterycontact / Batteryclip	MPD	6
BK-868	Batteryholder / Batterycontact / Batteryclip	MPD	48
BK-870	Batteryholder / Batterycontact / Batteryclip	MPD	5
BK-874	Batteryholder / Batterycontact / Batteryclip	MPD	40
BK-875	Batteryholder / Batterycontact / Batteryclip	MPD	111
BK-876	Batteryholder / Batterycontact / Batteryclip	MPD	80
BK-880	Batteryholder / Batterycontact / Batteryclip	MPD	8300
BK-883-TR	Batteryholder / Batterycontact / Batteryclip	MPD	3150
BK-883	Batteryholder / Batterycontact / Batteryclip	MPD	660
BK-885-TR	Batteryholder / Batterycontact / Batteryclip	MPD	19200
BK-912	Batteryholder / Batterycontact / Batteryclip	MPD	258
BK-912TR	Batteryholder / Batterycontact / Batteryclip	MPD	7700
BK-913	Batteryholder / Batterycontact / Batteryclip	MPD	14500
BRX1-2032-SM-TR	Batteryholder / Batterycontact / Batteryclip	MPD	48500
BS1225-PC	Batteryholder / Batterycontact / Batteryclip	MPD	9050
BS2450	Batteryholder / Batterycontact / Batteryclip	MPD	240
BS3	Batteryholder / Batterycontact / Batteryclip	MPD	650
BS7	Batteryholder / Batterycontact / Batteryclip	MPD	9800
BSF	Batteryholder / Batterycontact / Batteryclip	MPD	25
BSR	Batteryholder / Batterycontact / Batteryclip	MPD	3312
BU1632SM-JJ-GTR	Batteryholder / Batterycontact / Batteryclip	MPD	6500
BU2032SM-G	Batteryholder / Batterycontact / Batteryclip	MPD	5200
BU2032SM-HD-G	Batteryholder / Batterycontact / Batteryclip	MPD	3312
BU2032SM-JJ-GTR	Batteryholder / Batterycontact / Batteryclip	MPD	16200
BU2032SM-JJ	Batteryholder / Batterycontact / Batteryclip	MPD	250
BU2032SM	Batteryholder / Batterycontact / Batteryclip	MPD	5
BU2450SM-JJ-GTR	Batteryholder / Batterycontact / Batteryclip	MPD	1250
BV1632-G	Batteryholder / Batterycontact / Batteryclip	MPD	34300

CB-AA-PC-NEG	Batteryholder / Batterycontact / Batteryclip	MPD	120
CB-AA-PC-POS	Batteryholder / Batterycontact / Batteryclip	MPD	120
CB-AAA-PC-NEG	Batteryholder / Batterycontact / Batteryclip	MPD	120
CB-AAA-PC-POS	Batteryholder / Batterycontact / Batteryclip	MPD	120
EJ508A	DC Jack	MPD	250
ZA5350	Batteryclip	MPD	30